

CARE AND MAINTENANCE







Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE& IMPORTANT SAFETY INSTRUCTIONS


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- *The external flexible cable or cord of this luminaire cannot be replaced;
If the cord is damaged, the luminaire shall be destroyed

**This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. this plug will fit in a polarized outlet only one way. if the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. never use with an extension cord unless the plug can be fully inserted. do not attempt to defeat this safety feature.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
B.E.J.L	Lamp base		1X	N	Shade		1X
C	SCREW		1X	F.K	SCREW		2X
R	Finial		3X	P	Bulb		1X

**Product Dimensions:
L74" X W18"XH84"**




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 15 minutes.

1. Put the lamp base (A) on a flat surface.
2. Insert Tube(B) into base(A)
3. Insert Arm(E) into coupling(D) and secure it with thumb screw(C)
4. Insert Arm(J) into arm(E) and secure it with screw(F)
5. Insert Arm(L) into arm(J) and secure it with screw(K)
6. Put shade(N) onto socket(M) and secure it with socket ring(O)
7. Put PS panel(Q) onto the shade(N) and secure it with Finial(R)



ENJOY YOUR LAMP