


# Pantry

## IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.






Do not use power tools above 8 volts to assemble.



## Part List



## Hardware List



## Assembly Instructions 2/7

### IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the screws until each part is properly assembled.
- The unit must be level to work properly. Use the included adjustable levelers to level.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

### STEP 1

Attach Rail (N) to Side Panel (B), then flip Lock. (See Figures 1 and 2)

Slide Back Panel (I) into position.

Attach Upright (J) to unit.

Slide Back Panel (I) into position.

Attach Rail (N) to unit, then flip Lock.





Figure 1




Figure 2





Figure 3



### STEP 2

Attach Magnet to Rail (M) with Wood Screws for Magnet into pre-drilled holes. (See Figure 3)

Attach Rail (M) to unit with Wood Screw (long).

Attach Side Panel (C) to unit, then flip Locks.



Insert Wood Screw (long) into pre-drilled hole in unit, then tighten.

## Assembly Instructions 3/7

### STEP 3

Place Base (E) upside down on a soft cloth.

Attach Feet (F) to Base (E).




### STEP 4

Turn over base unit to its' upright position.

Attach unit from Step 2 to base unit,  
then flip Locks.

Attach Middle Panel (D) to unit, then flip Locks.



### STEP 5

Place Top (A) upside down on a soft cloth.

Attach Magnet to Top (A) with Wood Screws for Magnet  
into pre-drilled holes.

**STEP 6**

Attach Rail (N) to Side Panel (G), then flip Lock.



Slide Back Panel (K) into position.

Attach Upright (L) to unit.

Slide Back Panel (K) into position.

Attach Rail (N) to unit, then flip Lock.

Attach Side Panel (H) to unit, then flip Locks.



**STEP 7**

Attach unit from Step 5 to unit from Step 4, then flip Locks.

Insert Adjustable Pins into side panels at desired level.  
(See Figure 4)





Figure 4

# Assembly Instructions 5/7

## Drawer (T)



### STEP 8

Attach Drawer Sides (T3) and (T4) to Drawer Back (T2), then flip Locks. (See Figures 5 and 6)








Figure 5

Figure 6

### STEP 9

Slide Drawer Bottom (T5) into groove.

Attach Drawer Front (T1) to unit, then flip Locks.



### STEP 10

Attach Knobs with Machine Screws.


## Part List




T1.  
Drawer Front  
1 pc.



T2.  
Drawer Back  
1 pc.



T3.  
Drawer Side  
1 pc.



T4.  
Drawer Side  
1 pc.



T5.  
Drawer Bottom  
1 pc.

## Assembly Instructions 6/7

### STEP 11

Place Shelves (S) into position.

Attach Doors (O), (P), (Q) and (R) to unit by sliding door hinges into side panel hinges. (See Figure 7)

Attach Knobs to Doors (O), (P), (Q) and (R) with Machine Screws (long).

Attach Top (A) to unit, then flip Locks.

Slide Drawer (T) into position.






Figure 7



### STEP 12

Level unit by adjusting the adjustable levelers on bottom of unit. (See Figure 8)

Insert Wood Screws into pre-drilled holes in unit, then tighten.

Note: Unit must be level before tightening these screws.




Figure 8

# Assembly Instructions 7/7

## IMPORTANT

- To help reduce the risk of the unit tipping over, the Tip-over Restraint must be installed following these instructions exactly.

## STEP 13

Place unit at desired location.

Drill a 3/8" hole in wall in-line with the pre-drilled hole at top of unit.

Move unit.

Insert Anchor into the wall hole and attach Bracket with Wall Screw.

Attach Bracket at pre-drilled hole at top of unit with Wood Screw.

Move unit back into place.

Slide Tip-over Restraint through Bracket on wall and Bracket on unit. (See Figure 9)

Put tie end of Tip-over Restraint into lock end of Tip-over Restraint and pull until tight.







Figure 9




## Hardware List



Anchor  
1 pc. (+1 extra)



Bracket  
2 pcs. (+1 extra)



Tip-over Restraint  
1 pc. (+1 extra)



M3.5x40  
Wall Screw  
1 pc. (+1 extra)



M3.5x16  
Wood Screw  
1 pc. (+1 extra)