





Installation & Assembly

Version:1.0




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.















EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.



















EN_Turn cam lock clockwise to tighten.

PACKING DETAILS


| NO. | PARTS | QTY | SPARE |
|-----|---|-----|-------|
| ① |  | x1 | |
| ② |  | x1 | |
| ③ |  | x1 | |
| ④ |  | x1 | |
| ⑤ |  | x2 | |
| ⑥ |  | x2 | |
| ⑦ |  | x4 | |
| ⑧ |  | x8 | |
| ⑨ |  | x4 | |
| |  Hardware Kit | x1 | |



| | | | | | |
|---|--|---|---|---|--|
| <p>A x10 Ø6x35mm +1(spare)</p>  | <p>B x10 Ø15x10mm +1(spare)</p>  | <p>C x10 Ø6x30mm +1(spare)</p>  | <p>D x16 Ø4x35mm +1(spare)</p>  | <p>E x56 Ø3.5x12mm +4(spare)</p>  | <p>F x8</p>  |
| <p>G x8</p>  | <p>H x8</p>  | <p>I x1 M5</p>  | <p>J x12 +2(spare)</p>  | <p>K x2 Ø6x30mm</p>  | <p>L x4</p>  |
| <p>M x2</p>  | | | | | <p>R x4</p>  |

| | |
|--|--|
| <p>E x4</p>  | <p>F x4</p>  |
|--|--|



01





A x4

E x4


F x4



D x2





B x2



B x2



C x2

D x4





C x2

D x8





A x6

M x2





B x6

C x6



D x2

K x2



First fix the anti-rewind screw in the reserved hole of the product.

(1)x2


WALL

+
drilling hole
Ø6x30mm



(2)x2


Then use a tape drill to make holes in the wall that are suitable for the product screws.




Then, put the expansion bolt into the hole

(3)x2

WALL






Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.



E x40

L x4

R x4









x4

G x8



H x8


I x1





OR





OR

