

CPS

ASSEMBLY INSTRUCTIONS





IMPORTANT SAFETY INSTRUCTIONS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

1. Assembly

- For additional illustrated assembly steps, refer to the end of the written instructions.

2. Before First Use

- Suffocation Hazard: Packaging and small parts (screws, bolts, fasteners) may cause suffocation. Keep them away from children and pets, and secure all parts tightly during assembly.
- Children's Safety: Never leave children unattended with the chair. Teach children not to play with the chair, as it is not a toy. Climbing on the chair or playing with its moving parts can lead to falls or injuries. Additionally, ensure the chair is adjusted to a safe and appropriate height for children's use to prevent their feet from dangling, which can cause discomfort or pressure.
- Be mindful of pets around your chair. Chewing or clawing may damage the chair or create small parts that cause injury or health issues. Use protective covers or deterrents if your pets tend to chew furniture.
- Remove all the packing materials.
- Review all components before assembly. Check the product for transport damages.

3. Safety Instructions

When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

- This product must be assembled by an adult.
- Wearing gloves during assembly is highly recommended.
- Keep children and pets away while assembling the product.
- Do not let children climb on or play with the product.
- Always use the product on a firm, level ground.
- Do not use this product if any parts are missing, damaged, or worn.
- To avoid scratching the floor, assemble the product on a soft surface, such as a carpet.
- Do not over-tighten the fasteners.
- Regularly examine the product for wear and tear. Stop using the product at the first sign of damage or if parts become detached.
- Do not use power tools to assemble the product. Power tools may strip or damage the parts.
- Do not stand on the seat or sit on the armrests.
- Keep all sharp objects away from the upholstery.
- Do not hang anything on the product.
- Always keep the entire base of the chair in contact with the floor.
- If the chair is wobbly, tilted, or unstable do not continue using the chair until it is fixed or replaced.
- Do not lean back in the chair by either lifting the front legs off the ground or forcing the back of the chair into a horizontal position.
- Do not lean too far forward in the chair or sit too far forward on the edge of the seat because this can result in an unexpected tip-over.
- Ensure all wheels are securely installed. Do not sit on the chair if the wheels are not fully installed.
- Ensure the detachable leg is fully and securely installed before use. Do not sit on the chair if the detachable leg is not completely installed in the socket.
- Overloading the chair may result in breakage or injury.




PRODUCT PRECAUTIONS

DO NOT STAND ON THE SEAT OR SIT ON THE ARMRESTS



Do not stand on the seat or sit on the armrests. The chair is not designed to support body weight in this manner and doing so may cause loss of balance or injury from falling.

DO NOT TILT THE CHAIR BACKWARD BEYOND ITS LIMIT



Do not lean back by lifting the front legs off the ground or forcing the backrest into a horizontal position. This may cause the chair to tip over and result in injury.


※Please make sure all the parts are included.




BACK X1



SEAT X1




ARMREST X2




CONTROL
MECHANISM X1




WHEEL X5




BASE X1



GAS LIFT
CYLINDER X1



A X4
(SEAT)



B X4
(BACK)



C X4
(CONTROL
MECHANISM)



D X8
(WASHER)





E X1
(ALLEN KEY)


※ Detachable base leg is packed in a separate box.

⚠ NOTICE

Do not tighten the bolts all the way before each bolt is in place per step.




Please use the **Allen key** included instead of an electric drill.



TIPS!

Use the box for an easier assembly.




Enjoy your new favorite chair

Our goal is to create a perfect customer experience.




• Instructions


STEP 1 Bottom



1. Insert the base leg vertically into the base.




2. Press down firmly until the base leg is **FULLY SECURED**.







3. Fix the base leg with one hand and insert five wheels into the base.

SAFETY CAUTION




Ouch! Be careful not to get your hands caught in the gap.






4. Turn the base over.




5. Insert gas lift cylinder into the center of the base.


STEP 2 Top




For proper alignment:
Slightly **under-tighten** the bolts.




Order of bolts for better durability.




6. Line up the armrest and the back. Loosely tighten with two bolts. Repeat on the other side.






For proper alignment:
Slightly **under-tighten** the bolts.



7. Put the armrests on the bottom of the seat and tighten with two bolts on each side.




- 8.** Once all of the armrest bolts are in place, **fully tighten** every bolt.



- 9.** Align the control mechanism with the 'Front' sticker and secure it to the seat.

STEP 3 Top + Bottom



- 10.** Mount the seat onto the gas lift cylinder.

Done!




• User Manual

Check

Right hand


Tension Adjustment

Tilt Tension



Clockwise: tighten tilt tension.
Counterclockwise: loosen tilt tension.


Tilt Lock



While backrest is upright: push lever in to lock tilt, pull out to enable tilt.

Height

UP
↓
Down



**Enjoy your
new favorite chair.**

Our goal is to create a perfect customer experience.

• Care & Maintenance

Proper care and regular maintenance will help keep your chair clean and in good working condition.

CLEANING

- Clean regularly with a soft, dry or slightly damp cloth.
 - Wipe up spills promptly with a clean cloth.
 - Do not use abrasive cleaners, harsh chemicals, or excessive moisture.
 - Follow any care instructions specific to the materials used on your chair.
-

REGULAR MAINTENANCE

- Periodically check and tighten all screws, bolts, and connections.
 - Make sure the casters, base, and other components remain securely attached.
 - Check regularly for signs of wear, looseness, or damage.
 - Do not use the chair if any component is damaged or unstable.
-

CARE TIPS

- Use the chair on a stable, level surface.
- Avoid prolonged exposure to excessive heat, direct sunlight, or moisture.
- Do not drag the chair roughly across the floor.
- Use the chair only as intended and within the recommended weight capacity.