

End Table

IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.


Do not use power tools above 8 volts to assemble.




Part List




A.
Cabinet
1 pc.



B.
Stretcher
2 pcs.



C.
Side Frame
2 pcs.




D.
Shelf
1 pc.

Hardware List



Hex Wrench
1 pc.



M6x12
Head Cap Bolt
8 pcs. (+1 extra)




Flat Washer
8 pcs. (+1 extra)



Small Hex Wrench
1 pc.



Spring Washer
8 pcs. (+1 extra)



M4x12
Wood Screw
4 pcs. (+1 extra)

Tool(s) required for assembly: Phillips screwdriver

Assembly Instructions 2/3

IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- Keep Hex Wrench as the bolts may need to be tightened in the future.





Figure 1

STEP 1

Attach Stretchers (B) and Shelf (D) to Side Frames (C) with Flat Washers, Spring Washers and Head Cap Bolts, tightening bolts only halfway. (See Figure 1)

Tighten all bolts.



STEP 2

Remove drawer from Cabinet (A).

Rotate drawer stop into position. (See Figure 2)






Figure 2

STEP 3

Place Cabinet (A) upside down on a soft cloth.

Attach unit from Step 1 to Cabinet (A) with Wood Screws.



STEP 4

Turn unit over to its upright position.

Remove handle on inside of drawer and attach to outside of drawer with machine screws.

Slide drawer into position.

CARE INSTRUCTIONS

NEVER

allow liquids to remain on furniture.
Absorption causes parts to warp
and split and finishes to delaminate.


NEVER

use glass cleaners on
finished furniture. Ammonia
chemically attacks the finish.



Do not use power tools
above 8 volts to assemble.

**PREVENT
CRACKING**



Do not place
in direct sunlight.

**PREVENT
FADING**




Do not write
directly on surface.

**PREVENT
MARKING**



Do not place hot
objects on surface.

**PREVENT
FINISH DAMAGE**



Do not use rubber
based placemats.

**PREVENT
DISCOLORING**




Do not use commercial
waxes and polishes.

**PREVENT
YELLOWING**

CLEAN

with a soft cloth moistened
in lukewarm soap and water.
Buff with a dry clean cloth.



We will provide replacements free of charge for missing or damaged parts within 1 year of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, we are under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info.