


Assembly Instructions

Caution: You must read this before you proceed

CHAIR





Caution: This Chair is NOT a TOY

Keep your child/ children at bay during the assembly process.

Whenever moving/lifting the Chair and to prevent damage to the Chair two adults are needed to execute these actions.

Parts List


Label	Picture	Description	QTY
A		Backrest Panel	1
B		Seat Panel	1
C		Leg Panel	2
D		Seat Cushion	1

Hardware

Label	Picture	Description	QTY
①		Bolt (M6x65mm)	5
②		Bolt (M6x35mm)	3
③		Spring Washer (M8.5x2mm)	11
④		Washer (M8.5x2mm)	11
⑤		Nut (Ø8x6mm)	5
⑥		Allen Key	1
⑦		Spanner	1

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Unpack and place all parts on a clean, non-marring surface.

Step 2



Place the Backrest Panel(A) facedown onto a clean, non-marring surface.
Align Seat Panel(B) to Backrest Panel(A) then attach using Bolts(②), Spring Washers(③), and Washers(④) with Allen Key(⑥).
Do not fully tighten the Bolts.


Step 3



Attach Seat Panel(B) to Backrest Panel(A) using Bolts(①), Spring Washers(③), and Washers(④) with Allen Key(⑥).

Do not fully tighten the Bolts.

Step 4




Attach Leg Panel(C) to Seat Panel(B) using Nuts(⑤), Spring Washers(③), and Washers(④) with Spanner(⑦).

Do not fully tighten the Bolts.


Repeat the same process with the remaining Leg Panel(C).

Step 5



Place the Chair on a LEVEL SURFACE.
Inspect it and make sure all parts are adequately connected.
Gently and gracefully, sit into to the Chair.
This will help to align all the parts at all joint areas.
Then get off the Club Chair and proceed to tighten the Bolts in a sequential manner.
When tightening the Bolts tighten sequentially.
DO NOT tighten any Bolt fully and then move on towards the next one.
If there are still wobbles, loosen the Bolts and execute this same process.

Step 6



Place Seat Cushion(D) into the Chair.
Attach the velcro of Seat Cushion(D) to the Chair as shown above.
Your Chair is ready for use.

This Chair can only be used on a flat, level surface.

Care & Maintenance

-  ● Do not put hot items directly on furniture surface
 -  ● Do not clean furniture with harsh cleansers or polish.
 -  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -  ● Children should not climb or jump on the furniture.
 -  ● Do not write on furniture without a padded barrier to protect the
 -  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -  ● Not for commercial use. For residential use only .
 -  ● Stains may be removed with mild soap solution and damp cloth.
-
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .