



# Bed

## **PRODUCT GUIDE & ASSEMBLY INSTRUCTIONS**



# Guidelines

## FAILURE TO FOLLOW THESE WARNINGS WHEN IN USE COULD RESULT IN INJURY

- Do not stand on the item or use as a step ladder
- Do not use this item unless all bolts and screws are firmly secured and fastened.
- Check all bolts and screws every 90 days. As necessary tighten if any are loose.
- Lift up then move. Pushing over or dragging this product can result in an injury or cause damage to the floor and piece.

# **WARNING:**

**DO NOT LET CHILDREN PLAY IN OR AROUND  
THE UNIT DUE TO THE POSSIBLE RISK OF INJURY.**


## **Pre-Assembly Preparation:**

Please read through this instruction booklet before beginning assembly of this item.

## **Two adults are recommended for assembly.**

- Clear out the space for assembly and lay out all parts on Parts List, extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children and pets until fully assembled.
- Please check for any loose screws and tighten them before you use.


# Parts List




A Headboard (1)




B Footboard (1)




C Side Rail (4)



D Headboard Legs (2)




E Footboard Legs (2)



F Side Rail Legs (2)



G Side Wing (2)



H Slat (2)



I Slat (1)


# Parts List




J Big Support Legs (2)




K Small Support Legs (8)



L Center Rail (4)



M JCB M8x20 (8)



N JCB M6x30 (8)



O JCB M6x40 (2)



P JCB M6x50 (12)



Q JCB M6x60 (8)



R Allen Key 100mm (1)

# Parts List



S Allen Key 70mm (1)




T CSK Screw 32mm (10)



U Spring Washers (10)




V Flat Washers (12)



W Adjuster (10)

# Step 1


Unzip the black non-woven fabric on the back of the headboard and remove all parts.



BACK VIEW


## Step 2

Attach the headboard legs (D) to the headboard (A) and the footboard legs (E) to the footboard (B) using M6 x 50 screws (P) and spring washers (U) as shown in the image. Use the 100mm Allen key (R) to tighten the screws.



## Step 3


Attach the side wings (G) to the headboard (A) using M6 x 50 screws (P), spring washers (U) and flat washers (V) as shown in the image. Use the 100mm Allen key (R) to tighten the screws.



**Attention: Zip the black non-woven fabric after tighten the Screw !!**


## Step 4

Attach the side rail legs (F) to the side rails (C) using M6 x 30 screws (N) and flat washers (V) as shown in the image. Use the 100mm Allen key (R) to tighten the screws.




## Step 5

Attach the side rail (C) to the headboard (A) and footboard (B) by pushing the bracket down. Use M8 x 20 screws (M) to secure the headboard (A) to the side rails (C) and use the 100mm Allen key (R) to tighten the screws.




## Step 6

Attach the support legs (K) to the slats (H) and use M6 x 60 screws (Q) to secure the pieces. Tighten the screws by using the 100mm Allen key (R).



## Step 7


Attach the support legs (J) to the slats (I) using M6 x 40 screws as shown in the image. Tighten the screws by using the 100mm Allen key (R).




**ATTENTION:**  
Please keep the adjuster around 5 to 8 mm distance away from the floor.

## Step 8

Tighten the four corners of the bed by using the 70mm Allen key (S). Install the bed slats to the side rail and tighten the slats by using the CSK Screw 32mm (T) as shown in the image. The distance of the slats allows for desirable bed stability.



# Product Dimension



# Limited Warranty

The manufacturer's products are warranted against defects in material and workmanship while owned by the "Original Purchaser". The term "Original Purchaser" is defined as the party or entity which purchases this manufacturer's furniture from an authorized retailer as shown by the original sales receipt. This warranty does not apply to "as is" or previously owned products.

The manufacturer warrants its products to be free from defects in materials and workmanship (normal wear and tear, fading and stretching excepted), for one year from the date of purchase, except as provided below under the limited warranty. The exceptions or exclusions to this warranty are as follows:

1. Any warranty claim that is submitted after the limited warranty period, or without proper proof of purchase will not include the cost of parts, labor, or delivery.
2. This warranty shall not apply to the manufacturer's products which have been subjected to misuse, neglect, alteration, modification, or attachments, either caused by the Original Purchaser, shipping, storage, accident, fire, flood, or acts of God.

In the event of a defect in material or workmanship covered by this warranty, the manufacturer will repair or replace, at their discretion, without charge the warranted parts within a reasonable amount of time. We reserve the right to require damaged parts be returned to us upon request. Natural markings such as scars, brands, grain variations, wrinkles, color variations, etc. will be considered normal characteristics and not construed as defects.

For claims or questions concerning this warranty, please contact customer service department. Be prepared to provide your name, address, daytime phone number, the model and purchase order number of the product, date of purchase, and the website where it was purchased. The manufacturer requires that the original sales receipt be submitted with all requests to confirm that you are the Original Purchaser according to our written warranty.

This warranty gives you specific rights, and you may also have other rights, which vary from state to state (or country to country). All warranties are limited to the Original Purchaser for normal use.