OWNER'S MANUAL




BAMBOO TOP KITCHEN CART

PARTS LIST

Your Bamboo Top Kitchen Cart should include the following parts. Please inspect box contents to ensure you have received all components.

If you are missing any parts, need assistance with assembly or have questions, please contact Customer Service. Parts can also be requested.

You will need no additional tools for assembly.





Note: The black circular plastic tops in between the Shelves are used only for packaging purposes. They are NOT NEEDED. Please discard.

STEP 1

Screw each CASTER (J & K) into the bottom of each BOTTOM POLE (A). Turn clockwise to screw in place. Make sure LOCKING CASTERS are on the same side.

<u>Use provided caster wrench to tighten</u> <u>completely. Failure to do as instructed could</u> <u>result in the caster stem breaking.</u>






STEP 2

On BOTTOM POLE (A), place 1 pair of SLIP SLEEVES (I) at the desired level no higher than the 3rd indentation from the bottom. Please make sure the arrow faces up and that the word "TOP" is right-side up. Do this for each BOTTOM POLE (A) and make sure slip sleeve heights are identical for all BOTTOM POLES (A).

Note that each POLE (A & B) has slight horizontal line indentations at 1" intervals. Each SLIP SLEEVE (I) has raised horizontal lines inside designed to lock in place on the POLE (A & B).

Slide the pair of SLIP SLEEVES (I) until you hear a click to confirm the pair is locked onto BOTTOM POLE (A). DO NOT place more than one pair on each POLE (A & B) at a time.



^{*} Note: There will be a very small gap in-between two locked SLIP SLEEVES (I)—this is normal.

STEP 3

Place SHELF – LIP DOWN (E) on its side and slide (4) BOTTOM POLES (A) through (4) corner cylinders of SHELF – LIP DOWN (E). Make sure the corner cylinders are positioned over SLIP SLEEVES (I).




E (1)

Slowly stand the unit upright.

*The level side of SHELF – LIP DOWN (E) is the TOP side (our logo on the corner cylinders should be right-side up).

**Use a rubber mallet, if needed, to secure SHELF (E).




STEP 4

Screw TOP POLES (B) into BOTTOM POLES (A). Pole Connectors are pre-installed in bottom of the TOP POLES (B).



B (4)

The tops of TOP POLES (B) are indicated by BLACK END CAP.




STEP 5


Repeat Step 2 for BASKET (C), CART HANDLE (G), and SIDEBAR w/4 HOOKS (H), and slide each piece onto SLIP SLEEVES (I).





Only install ONE item at a time. Make sure to put SLIP SLEEVES (I) at the desired heights for each item.

*Use a rubber mallet, if needed, to secure BASKET(C), CART HANDLE (G), and SIDEBAR w/4 HOOKS (H).











STEP 6

Repeat Step 2 for SHELF - LIP UP (F) and place SLIP SLEEVES (I) at the highest position on the Top Pole. Slide SHELF - LIP UP (F) onto SLIP SLEEVES (I).





STEP 7


Place BAMBOO CUTTING BOARD (D) on top of SHELF — LIP UP (F). The grooves on the bottom of BAMBOO CUTTING BOARD (D) will fit exactly on SHELF — LIP UP (F).



**Using food safe oil regularly will prevent your BAMBOO CUTTING BOARD (D) from becoming dry and brittle.




D (1)



SERVICE PARTS LIST

Our Customer Service provides the following replacement parts:



WARNINGS

- Read and understand all instructions. Failure to follow all instructions may result in injury and/or damage.
- 2. Use the provided caster wrench to tighten casters completely. Failure to do as instructed could result in the caster stem breaking thereby causing the cart to collapse.
- 3. The warnings, cautions, and instructions discussed in this manual cannot cover all possible conditions or situations that may occur. The user must always be aware of their environment and ensure that they use the product in a safe and responsible manner.
- **4. Do NOT modify the product in any way.** Unauthorized modification may impair the function and/or safety of the product, and may affect the life of the product.
- 5. Check for damaged parts. Before using this product, carefully check that all parts are in good condition, and that the product will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts, and never use this product with a damaged part.
- 6. Do NOT overload the product.

Weight capacity per Shelf (evenly distributed)	200 lb
Weight capacity per Basket (evenly distributed)	65 lb
Total weight capacity of Cart (evenly distributed)	500 lb

CARE AND MAINTENANCE

- Avoid harsh, abrasive cleaners, and other corrosive chemicals.
- Bamboo board should be hand washed only and periodically treated with food safe oil.

PRODUCT REGISTRATION

Thank you for purchasing this Bamboo Top Kitchen Cart. In order to register your product and receive streamlined customer service, please fill out the following Product Registration For. Include a copy of your original receipt with your submission.

First Name:	Last Name:
Address:	
City:	_ State: Zip Code:
Email Address:	Phone:
	Purchase Date://
Location of Purchase:	
Please rate the importance of each feature (1=least important; 10=most important) Quality Price Size/Capacity Appearance Other	
How did you hear about our product? Magazine Ad Catalog Salesperson Word of Mouth Internet Store Display Other	
=	☐ Married 550,000 ☐ \$50,000-\$150,000 ☐ \$150,000+ chool ☐ College ☐ Graduate School ☐ Rent

1 YEAR LIMITED WARRANTY

Bamboo Top Kitchen Cart

We warrant to the original consumer purchaser ("Purchaser") of the Bamboo Top Kitchen Cart ("Product") that each Product shall be free from defects in workmanship and materials for a period of 1 year from the date of original purchase. Our obligation under this warranty shall be limited to repair or replacement of, or adequate compensation for the Product which shall not be greater than the amount of the purchase price of the Product, at the option of us, during the warranty period. All replaced parts and Products become the property of us and must be returned to us.

This warranty excludes normal wear and tear of the Product and its parts or components, and damage arising from any of the following: negligent use or misuse of the Product, use contrary to this User's Manual, or alteration by any one other than us. The warranty period of 1 year shall not be extended or renewed by the repair or replacement of, or compensation for, the Product. Any warranty implied by applicable law is limited in duration to one year from the date of purchase and is subject to the same conditions and limitations as is provided for our express warranty.

Except as set forth herein, and to the extent of applicable there are no warranties on this Product either express or implied, and we disclaim all warranties including, but not limited to, any implied warranties of merchantability, infringement or fitness for a particular purpose. No warranty or guarantee given by any person, firm, or corporation with respect to this product shall be binding on us.

If your Product is defective or otherwise requires service or parts, please call Customer Service toll-free. Please tell us which model you purchased, the date of the purchase, and the problem with your Product. A copy of your original purchase receipt must accompany your service request.

LIMITATION OF REMEDIES AND LIABILITY

We (and our employees, officers, members, managers, affiliates an assigns) shall not be liable for any incidental, consequential, special, indirect, remote, special or punitive damages for breach of any warranty, express or implied, including, but not limited to, lost profits, lost savings, loss of anticipated benefits and attorneys' fees, which arise out of the purchase, use or inability to use the Product, whether arising out of contract, negligence, strict tort, product liability, or any other legal theory on which a claim is based. As noted above, to the extent damages are allowed by our express warranty or by applicable law, those damages may not exceed the purchase price paid for the Product. Without limiting the foregoing Purchaser assumes all risk and liability for loss, damage or injury to Purchaser and Purchaser's property and to others and their property arising out of the use, misuse, or inability to use this Product. This limited warranty shall not extend to anyone other than the original purchaser of this product, is nontransferable and states your exclusive remedy.

Some states do not allow the exclusion or limitation of incidental, consequential, special, or punitive damages, so the above limitation or exclusion may not apply to you. The above warranty gives you specific legal rights, and you may have other rights which vary from state to state.

QUESTIONS? NEED PARTS? WE ARE HERE TO HELP!

Please feel free to contact us. There are no questions too small, or any problems too big. We're committed to providing our customers with the highest level of service.