



ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- | | |
|---|--|
| ☐ Are you missing anything?
Double-check all parts, hardware and accessories listed are all accounted for. | ☐ Check out our Quick Tips!
We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then! |
| ☐ Should we send any replacements?
Are there any irregularities or flaws in the parts? We can send replacements! | ☐ Prep Time!
Please review the assembly instructions and all diagrams prior to assembling. |
-

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.


After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

4 PC COUNTER HEIGHT. DINING SET




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

1



CUSHION SEAT

3 pcs.


2



STOOL LEG

12 pcs.


3



STOOL LONG
STRETCHER

6 pcs.

4



STOOL SHORT
STRETCHER

6 pcs.

5





TABLE TOP

1 pc.


6



LEFT TABLE LEG

1 pc.

7



RIGHT TABLE LEG

1 pc.

8



TABLE CENTERLINE RAIL

1 pc.

9




TABLE BACK RAIL

2 pcs.

STOOL HARDWARE

A



BOLT
Ø1/4" x 2"
24 pcs.

B



SPRING WASHER
Ø1/4"
24 pcs.

C



FLAT WASHER
Ø1/4"
24 pcs.

D



SCREW
45mm
24 pcs.


E



ALLEN WRENCH
M4
1 pc.

TABLE HARDWARE

F




BOLT
Ø5/16" x 1-3/4"
4 pcs.

G



SPRING WASHER
Ø5/16"
4 pcs.

H




FLAT WASHER
Ø5/16"
4 pcs.

I







SCREW
45mm
6 pcs.

J



ALLEN WRENCH
M5
1 pc.

Carton	Disignation	Part			
	CUSHION SEAT	1		 A x 24pcs	
				 B x 24pcs	
	STOOL LEG	2		 C x 24pcs	
				 D x 24pcs	
	STOOL LONG STRETCHER	3		 E x 1pc	
	STOOL SHORT STRETCHER	4		 F x 4pcs	
				 G x 4pcs	
				 H x 4pcs	
	TABLE TOP	5		 I x 6pcs	
	LEFT TABLE LEG	6		 J x 1pc	
	RIGHT TABLE LEG	7			
	TABLE CENTERLINE RAIL	8			
	TABLE BACK RAIL	9			

ASSEMBLY INSTRUCTIONS

1

Part 1 x1pc

Part 2 x4pcs

Part 3 x2pcs

Part 4 x2pcs

Hardware A x8pcs

Hardware B x8pcs


Hardware C x8pcs

Hardware D x8pcs

Hardware E x1pc

DO NOT FULLY TIGHTEN ALL BOLTS UNTIL
ASSEMBLY IS COMPLETED.

Align legs (2) to the cushion seat (1).
Position the stretchers (3,4) onto the legs.
Then secure legs onto the cushion seat (1)
by using bolts (A) with washers (B,C).




Secure the stretchers (3,4) to the
legs (2) by using screws (D.)

ASSEMBLY INSTRUCTIONS

2

Part 8 x1pc
Part 9 x2pcs
Hardware I x2pcs




Align Centerline rail (8) to the Back rail (9) Position the Back rail (9) onto the Centerline rail (8) . Then secure by using screw (I)

Flat head screw driver

3

Part 5 x1pc
Part 6 x1pc
Hardware F x2pc
Hardware G x2pc
Hardware H x2pc
Hardware J x1pc



Align Left leg (6) to the Table top (5) then secure by using Bolts (F) with washers (G,H).


ASSEMBLY INSTRUCTIONS

4

Hardware I x3pcs

Flat head
screw driver

Align Centerline rail & Back rail
(8,9) onto the Top & Leg.
Then secure by using screw (I)



5

Part 5 x1pc

Part 7 x1pc


Hardware F x2pc

Hardware G x2pc

Hardware H x2pc

Hardware I x1pc


Hardware J x1pc



Align Right leg (7) to the
Centerline rail (8) Then
secure by using screw (I)

Align Right leg (7) to the Table top
(5) then secure by using Bolts (F)
with washers (G,H).

ASSEMBLY INSTRUCTIONS



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.