DCM37

ASSEMBLY & INSTRUCTION MANUAL



DINING CHAIR

CONTENTS

01	WARNING	01
02	SAFETY INFORMATION	01
03	ASSEMBLY PARTS AND TOOL	02
04	ASSEMBLY INSTRUCTIONS	03
05	LIMITED WARRANTY	07

WARNING

Please read the instructions carefully and follow the assembly steps.

To ensure proper assembly, please follow all steps and use all parts provided. Not following this warning may result in serious injury to you or others.

To prevent misalignments, keep the screws loose and do not tighten them until they are all in their correct positions.

Avoid overtightening or forcing the screws, as this could cause them to break, strip, or damage the threads of the holes.

Using the wrong size of screws for a particular part could cause damage to the screw or the part.

Please lubricate all moving parts regularly and tighten all bolts and screws every 6 months, or as needed.

SAFETY INFORMATION

WEIGHT CAPACITY FOR PRODUCT: 275 LBS (≈125 KG)



Sit in the center of the chair with your back against the backrest



Do not sit at the front edge of the chair



Do not stand on the chair



Do not use the chair with more than one person



Do not push the chair around when a person is sitting in it



Do not push down on the backrest when a person is reclined




Do not place all your weight on the backrest only

ASSEMBLY PARTS AND TOOL

PLEASE MAKE SURE ALL THE PARTS ARE INCLUDED.


MISSING PARTS?
malolservice@hotmail.com

A




Leg *1

B




Leg *1

C



Bracket *1

D



Backrest *1

E



Seat Cushion *1

F



M6*30MM Bolt *1

G



M6*32MM Bolt *3

H



M6*12MM Bolt *4

I



M6*45MM Bolt *4

J



Wrench *1

BEFORE YOU GET STARTED, A FEW POINTERS:

Having a friend to help makes assembly extra-easy.


Please use the included wrench instead of an ELECTRIC HAND DRILL to avoid damage to the product.

ASSEMBLY INSTRUCTIONS

STEP 1 Cross the two legs with Leg (A) positioned above, then secure the pre-drilled hole at the base of the cross with Bolt (F), followed by tightening with Wrench (J).

Note1: Tighten all bolts to 50%.

Note2: Take the rubber sleeves off before assembly.




50%

STEP 2 Use your hand to push down the Backrest (D) mounting Bracket (C), secure the central hole with a Bolt (G), and fasten the sides with Bolts (G), then tighten with Wrench (J).

Note1: Tighten all bolts to 50%.

Note2: Take the rubber sleeves off before assembly.




50%

ASSEMBLY INSTRUCTIONS

STEP 3 Place the assembled chair frame on the ground, secure both sides of Bracket (C) with Bolt (H), and tighten them using Wrench (J).

Note: Tighten all bolts to 50%.




50%

ASSEMBLY INSTRUCTIONS


STEP 4 Place Seat Cushion (E) at the seating area of the chair frame, secure the leg frame to Seat Cushion (E) using Bolt (I), and tighten with Wrench (J).

Note: Tighten all bolts to 50%.



ASSEMBLY INSTRUCTIONS

STEP 5 Place a weight of up to 120KG or an adult sit on the chair, ensure balance, then tighten all bolts to 100%.If the legs are uneven, adjust the foot nails to level the chair.



STEP 6 Now, your chair is successfully installed.



LIMITED WARRANTY

We promise to repair or replace any chair that is found to be defective in material or workmanship within one year from the date of original purchase, as long as you, the original purchaser, still own it. This is your sole and exclusive remedy under this warranty, subject to the provisions outlined below.

EXCLUSIONS

This warranty does not apply to, and no other warranty applies to:

- Normal wear and tear, which is to be expected over the course of ownership.
- Misuse, abuse, or excessive use of the product.
- Modifications or attachments to the product that are not approved.
- Products that were not installed, used, or maintained in accordance with the product instructions and warnings.
- Products used for rental purposes or unauthorized retail activities.

Product Usage: Normal use for the product is defined as equivalent to a single shift, forty-hour (40) workweek. If the product is used in a manner exceeding this, the applicable warranty period will be proportionately reduced.

RETURN POLICY

We offer a 30-day return policy, meaning that all products purchased may be returned to us within that timeframe. You must contact us via email or customer service phone number within 30 days of receiving the product(s), and they must be returned to us without any undue delays.

CONDITIONS:

- Returned products must be in the same condition as received and returned in their original packaging.
- If the product is not faulty (i.e., if you change your mind or are unhappy with the product for another reason), you are responsible for the cost of return shipping. You must ensure the package arrives safely to us, so we recommend using a courier service that offers tracking.

LIMITED WARRANTY

- If the product is faulty when received, please contact us, and we will assist you with the return, covering the shipping costs in this case.
- We reserve the right to offer partial refunds for returned products that are not in unused condition, are damaged, or have missing parts not due to our error.

HOW RETURNS WORK

To request a return, please attach a copy of your invoice as proof of purchase, along with the reason for the return.

We will provide the return address for the product as soon as possible. Once the returned product is received and inspected, we will provide a specific resolution.

If the return is approved, the refund amount will be automatically credited to your original payment method.

MAINTENANCE INSTRUCTIONS



Dust and clean up spills immediately using a clean, non-colored, lint-free cloth.



Use a mild soap solution and a damp cloth to remove stains.



Do not place hot items directly on the furniture surface without using a protective barrier.



For indoor use only. Do not place the furniture outside.



Do not place furniture in direct sunlight.



Do not write on the furniture surface without a padded barrier to protect it.



Do not clean furniture with harsh cleaners or polishes.



Do not place furniture near heating or cooling vents (keep at least 3 feet away)

vimeo | ASSEMBLY VIDEO

+1(888) 868-6849
malolservice@hotmail.com