


IMPORTANT: READ CAREFULLY BEFORE BEGINNING

Do not tighten bolts until fully assembled.


WHEELBARROW PLANTER




PARTS AND HARDWARE LIST		
<p>①</p> <p>FRONT BEAM</p> <p>X 2PCS</p>	<p>②</p> <p>BACK BEAM (R)</p> <p>X 1PC</p>	<p>③</p> <p>BACK BEAM (L)</p> <p>X 1PC</p>
<p>④</p> <p>HAND RAIL</p> <p>X 2PCS</p>	<p>⑤</p> <p>WHEEL</p> <p>X 1PC</p>	<p>⑥</p> <p>HOPPER</p> <p>X 1PC</p>
<p>Ⓐ M06 - 4</p> <p>X 4PCS</p>	<p>Ⓑ M06-6</p> <p>X 4PCS</p>	<p>Ⓒ M06-6.5</p> <p>X 4PCS</p>

STEP 1:


Fix the Wheel (5) between 2PC of the Front Beam (1). Connect the Front Beam (1) and the Back Beam (2) & (3) with the Bolts (A).

**STEP 2:**


Put 2PC of the Handrails (4) in the Back Beam (2) & (3) respectively, then fix with the Bolts (B).

**STEP 3:**

Put the Hopper (6) on the assembled Front Beam (1) and Back Beam (2) & (3), then fix with the Bolt (C).

**STEP 4:**

Tighten all nuts, bolts, once every part and assembled pieces are in place.



**Congratulations
on your assembly!**

Limited Warranty and Care Instructions

LIMITED ONE YEAR WARRANTY (NON-TRANSFERABLE)

This product is covered under one (1) year limited warranty. To the original purchaser of this piece of furniture, cooler or accessory; we warrant that it will be free from defects in material and workmanship for up to one year from the date of purchase under normal use and proper care.

Replacement of defective or missing parts will be sent at no charge to the customer for a period of 30 days from the date of purchase. We will no longer be responsible for missing parts or hardware 30 days after date of purchase. Freight, packaging, labor or material charges to and from our customer service center is not covered under the warranty and is therefore the customer's responsibility.

The limited warranty does not cover this piece of furniture, cooler or accessory for commercial purposes, abusive use, damage by modification, freeze damage, rust, fading and issues caused by improper care.

For minor defects or missing parts/hardware, please contact customer service immediately upon purchase. Please do not return product to the store unless you are completely unsatisfied with the product, or if the damage is irreparable. A customer service agent may help determine whether the damage is reparable and will provide further instructions. For returns and refunds, please refer to your local store with proof of purchase for such cases.

Proof of purchase (dated register receipt) will be required for warranty claims.

PROPER CARE INSTRUCTIONS

If left untreated, wood will naturally weather. During long periods of non-use, store furniture or cooler in covered and dry place. For the least maintenance, place your furniture, cooler, or accessory under a covered area.

To preserve and maintain the original finish of Char-log/ Aspen log furniture, we recommend that a light lacquer coating be applied every 4 to 6 months depending on the seasons.

We recommended an exterior poly-urethane product that features a clear satin or semi-gloss finish and a fast drying process.