


Owner Manual



Due to the size of this product, the panels can be quite heavy. To ensure your safety and make the installation more efficient, we highly recommend teaming up with family or friends. Let's make assembly fun—we hope you enjoy the hands-on experience !

IMPORTANT! Please read all instructions before use and keep this manual for future reference.

ATTENTION



Attention Customers living in the United States and Canada

If you are missing parts, hardware, or if your product has been damaged during shipping



DO NOT RETURN YOUR PRODUCT

The store does not stock parts and may not be able to help you. Please contact us directly and **we will ship you the parts** you need to your shipping address **at no cost to you.**

※ Stay Scratch-Free: Safeguard Your Furniture by Assembling on Carpet.



※ Stuck in Assembly Limbo? Check out our website or contact our support team for quick solutions!




WARNING: ASSEMBLY NOTICE

Attention

Important Instructions for Assembling Your Furniture To ensure the longevity and integrity of your MDF furniture, please adhere to the following guidelines:

DO NOT USE AN ELECTRIC DRILL



Using an electric drill can cause irreversible **damage to the MDF boards**, leading to compromised structural integrity and potential voiding of your warranty.


IF AN ELECTRIC DRILL MUST BE USED

- **Set to Lowest Torque Setting :**

Ensure your drill is set to the lowest possible torque setting to avoid over-tightening and damaging the material.

- **Proceed with Caution :**


Carefully monitor the drilling process to prevent excessive force and damage.














For best results and to avoid any damage, we highly recommend using the provided manual tools or a handheld screwdriver.











Thank you for your attention and understanding.

PARTS LIST
















PARTS LIST




Item	Reference Image	Qty
1		x1
2		x1
3		x1
4		x1
5		x2
6		x2
7		x1
8		x1
9		x2
10		x2
11		x2





Item	Reference Image	Qty
12		x1
13		x2
14		x2
15		x4
16		x2
17		x2
18		x1
19		x2
20		x2
21		x1




HARDWARE

LIST

A  x48	B  x48	C  x35	D  x6
E  x20	F  ø3x16mm x20	G  ø4x22mm x12	H  ø4x40MM x6
I  ø3.5x12mm x24	J  x48	K  ø4x30mm x10	L  x8
N  ø4x14mm x48	O  x8		

M  a	 b	 c	 d	 e
x2				

CL 	DL 
CR 	DR 
x2	




2


B

I

CR











x3

x3


x1






4

C









x2

H



x2







6


A

C

J
















x10

x10


x10






8

15




x1




9

②




x1

③






x1

B



x14





10

I

CL





CR






x6

x1


x1






12

15




x1



13^A


x7

C







x2

J




x7




14

⑮



x2



15

1

8

B

C

H



x1

x1

x6


x4

x4




16

A




x6

C




x6

J




x6



17

E




x20

F




x20




18

⑪




x2

0




x8




19

⑩



x2

L




x4

N




x8



20

D



x2

G




x4

N



x16




Adjusting the door

- .Before adjusting the hinge, please check whether the cabinet is skewed
- .If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- .Please adjust the hinge with the door open
- .Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw
- .Have trouble adjusting the door? Please check out our video on adjusting the door via our website or contact!


21

⑨



x2

L




x4

N




x8



22

D



x2

G




x4

N



x16




Adjusting the door

- .Before adjusting the hinge, please check whether the cabinet is skewed
- .If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- .Please adjust the hinge with the door open
- .Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw
- .Have trouble adjusting the door? Please check out our video on adjusting the door via our website or contact!


23

14




x2

16




x2

17




x2

19




x2

20




x2

C




x2

K




x10



X2


24

21



x1

A




x5

B




x5

C










x3

J




x5



Reminder: Please check the matching drawer number carefully to avoid installing the wrong size and affecting normal drawer operation.


25

D



x1

G




x2

I




x6

DL




x1

DR




x1



Reminder: Please check the matching drawer number carefully to avoid installing the wrong size and affecting normal drawer operation.


26

18




x1

A




x5

B




x5

C










x3

J




x5



Reminder: Please check the matching drawer number carefully to avoid installing the wrong size and affecting normal drawer operation.


27

D



x1

G




x2

I




x6

DL




x1

DR





x1

DR




DL



Reminder: Please check the matching drawer number carefully to avoid installing the wrong size and affecting normal drawer operation.


28

Reminder: Please confirm the corresponding drawer ID to prevent misplacement and ruining the cabinet's overall look.



29


M




a



b



C



d



e


 x_2


WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.




Installation Instructions:

1. Hardware Set M consists of parts a, b, c, d and e.
2. Use part d to lock part a onto the side of Cabinet No. ①.
3. Confirm the placement of the furniture, and mark the wall for the screw holes of mounting bracket a.
4. Drill a 3/8-inch hole in the wall.
5. Press plastic anchor e into the hole and tap it lightly until the end of the anchor is flush with the wall. Then secure part a to the wall with long screws c.
6. Uncoil steel cable b, run it through the cabinet and the wall-mounted connector, then tighten steel cable b to fasten into place.





Components Name



Doors may need to be adjusted after the initial shipping of the cabinet . The cabinet doors have a three-way adjustment fea-ture. Height, side to side, level and depth can be adjusted. With the hinge slightly closed you can access the middle screw for up / down adjustment . With the hinge fully extended you can access the front and back screws. These screws will move the door side to side and in and out.

Warranty Information

Thank you for purchasing our furniture. We are committed to delivering high-quality furniture that meets your expectations. This product comes with a 1-year limited warranty covering defects in materials and workmanship under normal use from the date of purchase.

Warranty Coverage

Structural damage or defects in the wood panels.

Malfunction of hardware components such as hinges or screws.

Any damage caused during transit that affects product functionality.

Exclusions

Damage caused by improper assembly or modifications.

Issues caused by external factors such as moisture or extreme temperatures.

In case of any warranty claims, please contact our customer service team with your proof of purchase and a detailed description of the issue.

Quality Assurance (QA) & Common After-Sales Issues

We take pride in our rigorous quality assurance process to ensure every piece of furniture meets high standards. However, we understand that issues may arise. Below are some of the common after-sales concerns and their potential solutions:

Gaps Between Panels

If there are visible gaps between the panels, please check the assembly process to ensure all parts are securely fastened. If the issue persists, contact our customer service for assistance.

Misaligned Doors

In case the doors are not aligned properly, adjustments to the hinges may be needed. Instructions for adjusting the hinges are included in the manual. If adjustments do not resolve the issue, please contact us.

Shipping Damage

If your furniture arrives with any damage from shipping, such as dents or scratches, please report the damage immediately. We will arrange for a replacement or repair.

Incorrect Hole Alignment

If any holes for assembly are misaligned, please refrain from forcing the components together. Contact our customer service for troubleshooting or part replacement.

Thank You!

For Purchasing from us

Despite our reinforced packaging, transit mishandling can sometimes occur. In the rare event that your product arrives damaged, we're here to assist you. If your product is in perfect condition, you can disregard this message.

Additionally, we kindly request your assistance in filing a claim against the shipping carrier for the mishandling of your package. Please help us by providing clear photos as follows:

- ★ **Complete Shipping Label (Express Delivery Waybill):** Take a clear image of the entire shipping label affixed to the package with visible and legible text and barcodes
- ★ **Exterior Packaging Damage:** Capture a comprehensive photo showing the damaged exterior of the shipping package.
- ★ **Interior Item Damage:** Provide images focusing on the damaged areas of the product

Your cooperation is invaluable, and we assure you that we're committed to resolving this issue promptly. Your satisfaction remains our top priority.

Thank you for your understanding and assistance.

Best regards,