





BARBER CHAIR

———— User Guide ————






1




Please screw 4 pins up to base.

2



Please turn the pump upside down, using the screws with gaskets to install the pump into the base.


3



Please using the screw to install the foot lever.

Note: The pump latch are pre-positioned in the pump rod. Please align the foot lever with the flat groove which inside the foot lever hole and knock it in by hammer. Please turn the screw on counterclockwise.



4



Please using 3 screws to install the backrest on seat plate.

Note: The screws are pre-positioned on the backrest.


5



Please using the screws to install the hand levers in the seat cushion.

Note: The screws and gas piston are pre-positioned on the seat cushion.


6



Please place the seat on the pump.

Note: When the seat is placed on the pump, the latch of the pump needs to be aligned with the grooves of the tray.


7



Please using the screws to assemble the footrest together, install the footrest under the seat frame.

Note: The screws are pre-positioned on the 3 parts of footrest and seat frame.

8



Please assemble the footrest on the footrest and insert the headrest in the backrest.

COMMON PROBLEMS AND SOLUTIONS

Pump Not Working at All

Solution: It is because the pump got locked. Please push the lever to the lowest position and hold it for a few seconds, then it will be unlocked.

Pump Not Working Properly

Solution 1: The failure of pump to rise and down may cause by the wrong direction of the foot lever installation. Please take off the footrest first, then turn the foot lever in the opposite side and plug it into the pump again. For further details, please check the prompts in installation steps.

Solution 2: If the foot lever in the correct direction, the problem may cause by the air inside of the pump. For this circumstance, please rise the chair to highest position and then lower the chair to lowest position. Then, repeat the process several times. The pump should work properly.

Pump Goes Down by Itself

When you pump up the chair in daily uses, please do not tread the foot lever to the end. Please pump up the chair bit by bit from the lowest position to the highest position (without people sitting). Please upward the foot lever and let someone sit on the chair to see if the problem still exists, if the issue still exists, please contact us.

Difficult to Rotate

Solution 1: The issue may cause by wrong seat cushion installation, for placing the seat to the bottom, please push the seat down and it will be locked automatically.

Solution 2: The pump has two screws inside. Please remove the pump cover and loose the screws on the pump, which will make the chair to spin free.

Recline Not Working

Solution: If backrest cannot move forward or backward, please adjust the gas piston for the recliner. There is a screw on the piston, you need to adjust it a little bit to make the recliner works.

Chair Slant Forward

Solution: The issue is caused by wrong side bracket installation. There is a bracket between seat and pump. The bracket is not flat, it is designed in that way. Please put the thick side to the back, and thin side to the front, then the chair should work properly.

If you have any unsolvable problems, please contact us in time, we will do our best to help you solve them.

MAINTENANCE RECOMMENDATION

Surface Maintenance

- 1. Avoid using hard objects to scratch the chair surface. The leather fabric is wear-resistant, but it is easy to be scratched by hard objects. The sharp items such as scissors and razors used in the hair salon need to be placed properly. In addition, guests’ zippers, and buttons may scratched the leather surface of the hairdressing chair.
- 2. The leather surface material needs regular care. You can use the leather surface curingagent to spray and wipe the hair surface of the hairdressing chair from time to time for maintenance. If the chair surface is stained with dyes, perm agents and other difficult-to-clean items,you can use cotton cloth Wiping with a little petrol can effectively avoid hairdressing chair surface staining.

Hydraulic Pump Care

The main function is to adjust the height of the hairdressing chair through lifting. Generally, the Hydraulic pump will not have any quality problems. When buying the Hydraulic pump, be careful not to buy an Hydraulic pump that seeps oil. Usually, the hairdressing chair can be lifted by half-stepping. Putting one foot to the end and stepping on the way of half stop and half stop can effectively improve the service life of the hydraulic pump of the hairdressing chair.

Chassis Care

- 1. Do not wear on the electroplating chassis. You cannot use sandpaper or other materials to wipe the hairdressing chair chassis. The electroplated surface is usually chrome plated, which has the functions of anti-rust and anti-corrosion, so avoid grinding. If there is a bit of rust, you can choose to wipe with a dry cotton cloth. In addition, please clean the chassis frequently to keep the chassis clean.
- 2. The stainless steel chassis is relatively easy to care, just wipe it frequently.

WARRANTY INFORMATION

	3 Years
Metal Base	3 Years
Pump	1 Years
Reclining Mechanism 3 Months	3 Months
Headrest	
Backrest	
Seatrest	
Footrest	

LIMITATIONS APPLICABLE TO ALL WARRANTIES

All warranties are to the original purchaser
We will replace the defective parts or send replacement chair provided that the warranty parts have not been subjected to misuse, abuse or improper service by the consumer, for example, damaged wire arising in consequence of negligence or improper operation.

Exclusions also include components with damage caused by:

- Contamination
- Abuse, misuse, accident, or negligence
- Commercial use, or use other than normal
- Improper operation, maintenance, or storage

We will pay standard shipping rates on all warranted parts for the first year. We can also sellyou replacement part for discount price when your chair is out of warranty policy

RETURN/REPLACEMENT POLICY

All of lift recliners come with a 90-day return/replace policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged chair, through provide pre-paid return label or pick up service for customer’s convenience. We do not responsible for the returns that customer bought by mistake or changed their mind and other non-quality issues. The customer is responsible for freight costs unless the chair is defective. Chairs returned due to being refused by the customer or deemed undeliverable by freight carrier are subject to fees for freight both ways and a 20% restocking fee.