Assembly Instructions

Caution: You must read this before you proceed

Please look in the under table top for hardware packs

TABLE



CAUTION: This Table is NOT a TOY.

Keep your child / children at bay during the assembly process.

For moving the Table and to prevent damage to the Table, two adults are needed to execute this action.


Parts List					
Label	Picture	Description	QTY		
А		Center Table Top	1		
В		Side Table Top	2		
С		Table Support Bar	5		
D		Leg	4		
Hardwara					


Hardware

Label	Picture	Description	QTY
1	9	Bolt (M8x20mm)	13
2	Description	Bolt (M8x40mm)	31
3	0	Washer (M8.5/20x2mm)	13
4		Allen Wrench	2

Assembly Preparation

Before Beginning Assembly:







Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

Assembly Steps OVERVIEW Side Table Top (B) Center Table Top (A) Leg (D) Table Support Bar (C) FRONT FACING


This Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Unpack and place all parts on a clean, non-marring surface.




- 2.1) Place Table Top (A, B) with its underside facing skywards onto a clean, soft surface to avoid any scratch or damage to the product. Then connect them as the arrows.
- 2.2) Attach 5 Table Support Bars (C) onto the underside of Table Top (A, B) as shown in above picture.



- 3.1) Horizontally, secure 2 Table Support Bars (C) into both side of Center Table Top (A) and Side Table Top (B) using Bolt (2) and Allen Wrench (4).
- 3.2) Vertically, secure 3 remained Table Support Bars (C) into the middle of Center Table Top (A) and Side Table Top (B) as shown in above picture.


Do not fully tighten Bolts.



Attach Leg (D) to Side Table Top (B) using Bolt (1) and Washer (3) with Allen Wrench (4) as shown in above picture.

Repeat the same process with 3 remained Legs (D).

Do not fully tighten Bolts.



Stand the Table up, with assistance from your adult partner.

Exert pressure floorwards, onto the Table with both your hands.

This pressure will help the Legs and Table Top reach full alignment status.

Check for wobbles on a LEVEL surface.

If no wobbles are found proceed to tighten the Bolts in a sequential manner, until evenly secured.

When tightening the Bolts tighten sequentially.

Do not tighten any Bolt fully and then move on towards the next one.

If there are still wobbles, loosen the Bolts and excute the same above process. Your Table is ready for use.

This Table can only be used on the flat, level surface.

Care & Maintenance





Prolonged exposure to rain may cause rusting which can stain floors.





Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only.



Stains may be removed with mild soap solution and damp cloth.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.