


ASSEMBLY INSTRUCTIONS



Description : STORAGE CHEST 29 IN

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

WARNING:







Long exposure to rubber or soft plastic may cause a chemical reaction and damage the finish of your product. Protect the surface of the product with cloth if you are using any product with rubber feet or base.

ASSEMBLY TOOLS REQUIRED NOT INCLUDED










PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
A	Top panel	1		D	Front panel	1	
B	Back panel	1		E	Side panel (L&R)	2	
C	Support bottom panel	2		F	Bottom panel	1	

HARDWARE LIST


When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	BOLT (M6x30mm)	12		5	Short screw (M4x15mm)	22	
2	Spring washer (φ6.5x11mm)	12		6	Long screw (M4x30mm)	4	
3	Flat washer (φ6.5x13mm)	12		7	Allen key	1	
4	Hinge	2					

STEP 1


Attach Back panel (B) and Front panel (D) to Side panel (E) with Bolts (1), and washers (2), (3). Tighten with Allen key (7).

Attach Support bottom panel (C) to Back and front panel with Screw (6) as shown below. Tighten with a screwdriver.



STEP 2

Slide Bottom panel (F) into groove of the unit as shown below. Then attach Side panel (E) to the unit with bolts (1), washers (2) and (3). Tighten with Allen key (7). Attach top (1) to the unit with screw (5) as shown below. Tighten with a screwdriver.



STEP 3

Attach Hinges (4) to the unit with Screws (5) as shown below.

