





Product Instruction






IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.


IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.







Note:

1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screw with tools gradually.
4. If screw are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all screws, adjust it on a flat ground and tighten up all screws again.
6. Note: If one or some screws are fully tighten during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.


CARTON CONTENT:




① x 1




② x 1




③ x 1




④ x 1




⑤ x 1




HARDWARE




⑥ x 1




⑦ x 1



⑧ x 1




⑨ x 2




⑩ x 2



⑪ x 2



⑫ x 3




⑬ x 2



⑭ x 1




⑮ x 1



⑯ x 1




⑰ x 1




⑱ x 1




⑲ x 1



⑳ x 1




Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 14+1




Ø 6 x 35 mm

B x 12+1




Ø 15 x 9.5 mm

C x 12+1




Ø 6 x 30 mm

D x 2




Ø 15 x 11 mm

E x 4




Ø 8 x 30 mm

F x 12+1




Ø 4 x 40 mm

G x 9



Ø 6 x 30 mm


H x 14+1



J x 6



K x 2




Ø 8 x 30 mm

L x 4



M x 2




N x 24+2




Ø 4 x 12 mm

P x 4




Ø 4 x 30 mm

Q x 4



Ø 3 x 12 mm x 24

R x 4



Ø 3 x 12 mm

S x 12+1




T x 16+1



Ø 3 x 12 mm

U x 8



Ø 6 x 35 mm

V x 8



X x 8




Ø 4 x 12 mm


Y x 1




1





As shown in the figure, please tear one end of No. 19 with adhesive and place it in the molding place of No. 3 and No. 4 plates.
From here on, stick it evenly in the molding place for a week,
and remove the excess part.



2

A x 4  Ø 6 x 35 mm	C x 4  Ø 6 x 30 mm	Yx1  +	
---	---	---	--





3

G x 9
Ø6X30mm

C x 4
Ø6 x 30 mm

E x 2
Ø8 x 30 mm

Yx1



4

K x 1






Ø8X30mm

J x 6



Yx1





5

F x 4




Ø4X40mm





6

F x 4




Ø4X40mm





7

F x 2




Ø4X40mm





8

B x 2

Ø 15 x 9.5 mm

Yx1




9

K x 1







Ø8X30mm




Yx1





10




11




12

B x 2  Ø 15 x 9.5 mm	N x 2  Ø 4x12mm	Yx1 	
---	--	--	---



13






14

X x4





Ø 4x12mm

Yx1



15






16

X x4



Ø 4x12mm

Yx1





17

C x 4



Ø6 x 30 mm



18

A x 10



Ø 6 x 35 mm

E x 2



Ø 8 x 30 mm

M x 2







T x 4



Ø 3 x 12 mm

Yx1






19

P x 4




Yx1





20

D x 2

Ø 15 x 11 mm

Yx1






21


B x 8
Ø15 x 9.5 mm

Yx1





22

F x 2




Ø4*40mm




23



R x 4



Qx4



Yx1






24

Rx12



Ø 3 x 12 mm

Yx1



25

Qx4






Qx8



Ø 3 x 12 mm

Yx1



26

L x 4





N x 16



Ø 4x12mm

Yx1



27

Sx 12










T x 12




Ø3x12mm

Yx1



28

H x 14



V x 8

