


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)



2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES



When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Headboard




#2 x 1pc
Footboard




#3 x 2pcs
Side Rail



#4 x 2pcs
Side Rail



#5 x 2pcs
Slat



#6 x 2pcs
Slat




#7 x 6pcs
Support Leg


Hardware List



#A x 14pcs
Bolt 1/4" X 5/8"



#B x 8pcs
Bolt 1/4" X 3/4"



#C x 6pcs
Bolt 1/4" X 1-3/4"






#D x 28pcs
Flat washer




#E x 1pc
Allen Wrench



1. Prepare 6 bolt assemblies by inserting a flat washer (#D) onto the bolts (#A).




- #E 
- #A  X 6 pcs
- #D  X 6 pcs




2. Insert the side rails (#3) into the side rails (#4), then insert a bolt assembly into each rail and secure using the Allen wrench (#E).



1. Prepare 6 bolt assemblies by inserting a flat washer (#D) onto the bolts (#C).



- #E 
- #C  X 6 pcs
- #D  X 6 pcs



2. Align the support legs (#7) to the holes along the slats (#5, #6), then insert the bolt assemblies from above. Secure using the Allen wrench (#E).





1. Prepare 8 bolt assemblies by inserting a flat washer (#D) onto the bolts (#B).



2. Align one end of the side rails to the holes along the headboard (#1). Align the other ends to the footboard (#2). Insert the bolt assemblies into each hole and secure.




1. Prepare 8 bolt assemblies by inserting a flat washer (#D) onto the bolts (#A).



2. Place the slats (#5,6) onto the slots indicated in the image, then insert a bolt assembly into each hole and secure using the Allen wrench.



ASSEMBLY IS COMPLETED



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.