


WIDE STORAGE CABINET





**FOR REPLACEMENT PARTS OR HELP WITH
ASSEMBLY PLEASE CONTACT US**

**PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR INSTRUCTION BOOKLET**

**TO RETURN THE PRODUCT:
PLEASE CONTACT THE RETAILER
WHERE THE ITEM WAS PURCHASED FROM**

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required.
Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

CARE and MAINTENANCE

To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth.
Dust with soft dry cloth.









Do not use ammonia-based cleaning products, as they will damage the finish.
Do not leave liquids or damp cloths on this furniture.

To avoid dulling of the finish, do not place furniture in direct sunlight.

Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.

PRE-ASSEMBLY INFORMATION













PART DESCRIPTION




NEED HELP? For help with assembly or if you are missing a part,
Please call customer service


PRE-ASSEMBLY INFORMATION

HARDWARE DESCRIPTION

<p>1</p>  <p>ALLEN KEY SCREW M6 X 30mm QTY 18</p>	<p>2</p>  <p>CAM LOCK PIN CAM LOCK QTY 6 SETS</p>	<p>3</p>  <p>WOOD DOWEL M8 X 30mm QTY 8</p>	<p>4</p>  <p>ALLEN KEY QTY 1</p>
<p>5</p>  <p>PHILLIPS SCREW ROUND HEAD M4 X 15mm QTY 26</p>	<p>6</p>  <p>SHELF SUPPORT QTY 18</p>	<p>7</p>  <p>HANDLE M4 X 25 mm QTY 3 SETS</p>	<p>8</p>  <p>PHILLIPS SCREW M3 X 15mm QTY 12</p>
<p>9</p>  <p>MAGNET AND PLATE QTY 3 SETS</p>	<p>10</p>  <p>PHILLIPS SCREW M3 X 12mm QTY 18</p>	<p>11</p>  <p>PHILLIPS SCREW M4 X 25mm QTY 4</p>	<p>12</p>  <p>a. M4 X 25mm - 1PC b. M4 X 15mm - 1PC c. M4 X 25mm - 1PC TIPPING RESTRAINT QTY 1 SET</p>




Required -
Flathead screwdriver
Phillips screwdriver
Rubber mallet
Not Included




NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

COMPONENTS-KEY DIAGRAM



PRE-ASSEMBLY INFORMATION


STEP-1



1. Insert 2 Dowels (3) into pre-drilled holes on each Divider (C).
2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
3. Attach 2 Dividers (C) to Bottom Shelf (D) using 6 Allen Key Screws (1) (3 Screws on each Divider).
4. Use Allen Key (4) to tighten screws. Do not over-tighten.

ASSEMBLY


STEP-2



1. Insert 4 Dowels (3) into pre-drilled holes on Bottom Shelf (D) (2 dowels on each side).
2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
3. Attach 3 Cam Lock Pins (2) to each Side (B) using guide holes.
4. Align Cam Lock Pins with pre-drilled holes on Bottom Shelf (D).
5. Insert 6 Cam Locks (2) into pre-drilled holes on Bottom Shelf (D) (3 Cam Locks on each side).
6. Use flathead screwdriver secure Cam Locks.


ASSEMBLY

STEP-3



1. Attach Top (A) to Sides (B) and 2 Dividers (C) using 12 Allen Key Screws (1) (3 screws on each Side and Divider).
2. Use Allen Key (4) to tighten Screws. Do not over-tighten.


STEP-4



1. Attach Support Leg (H) to Bottom Shelf (D) using 4 Phillips Screws (11).
2. Use Phillips screwdriver to snugly tighten screw.

ASSEMBLY


STEP-5



1. Attach Back Panels (G) to back frame of cabinet using 26 Phillips Screws Round Head (5) through pre-drilled holes.
2. Use Phillips Screwdriver to tighten screws.

ASSEMBLY


STEP-6



1. Attach hinges on Door (F) to Side (B) and Divider (C) using Phillips Screws (10) into guide holes.
2. Attach Magnet Plates (9) to corners of Door (F) using Phillips Screws (8) into guide holes on Doors (F).
3. Attach Magnets (9) using Phillips Screws (8) into guide holes on Bottom Shelf (D).
4. Use Phillips screwdriver to snugly tighten screw.
5. Use Phillips screwdriver to attach Handle (7) to Door (F).

ASSEMBLY

STEP-7




1. Use 4 Shelf Supports ⑥ for each Cabinet Shelf ⑤ in desired location.
2. 2 Shelf Supports ⑥ may be used on back top of each Cabinet Shelf ⑤ as a tipping restraint.


ASSEMBLY

NOTE: Injuries and damage can occur from furniture tip-over. It is important to use the safety bracket included. If the tipping restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

STEP-8



NOTE: The screwdriver is not included in the hardware pack.



1. To attach Tipping Restraint (12), follow instructions on Tipping Restraint package.

When you determined the location for your unit, install the Furniture Tipping restraint. Carefully follow the instructions contained on the package.

WARRANTY

Thank you for purchasing our product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line or by email.

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.