







ASSEMBLY INSTRUCTION

Thank you for purchasing the quality product. Be sure to check all packing material carefully for all parts which may have come loose inside the carton during shipment. Separate, Identify and count all parts and metal hardware. Compare with all parts listed to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.


****Do not fully tighten screws until fully assembled****



HARDWARE LIST:			
NO.	Drawing	Description	Q'ty
A		FLAT WASHER (ø 5/16"x 19mm)	8PCS
B		SPRING WASHER(ø 5/16")	8PCS
C		BOLT(ø 5/16"x2")	8PCS
D		WRENCH 12 mm	1PC





TOP BASE 1 PC



SIDE FRAME 2 PCS

How to assemble & Steps



Attention

Some number parts listed on the instruction sheet may not be in parts bag as they may be assembled. Carefully check parts and packing materials prior to ordering replacements.

CLEANING INSTRUCTIONS

Clean the surface with a furniture polish and a soft cloth