


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Wrench

(Included)



Phillips
Screwdriver

(Not Included)



2 - People
Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note :


Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt



cam lock




screwdriver




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3

Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.

BOOKCASE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc




Top panel

#2 1pc




Upper Left Side Panel

#3 1pc



Upper Right Side Panel

#4 1pc




Divider shelf

#5 1pc




Divider panel

#6 1pc




Lower Left Side Panel

#7 1pc




Lower Right Side Panel

#8 1pc



Left door

#9 1pc



Right door


#10 1pc



Bottom panel

HARDWARE

#A 25pcs



Cam-bolt Ø8mm

#B 25pcs



Cam-lock Ø15mm

#C 2pcs



Handle

#D 2pcs



Handle bolt Ø5/32" x 1"

#E 12pcs



Screws #3 x 12mm

#F 2pcs



Magnet

#G 4pcs




Screws 3 x 15mm

#H 24pcs



Wood dowel Ø8 x 30mm

#I 1pc




Allen Wrench 4mm

#J 1set



Anti-Tip Skit

Exploded View




ASSEMBLY INSTRUCTIONS


1

Part **#1** x 1pc
Part **#10** x 1pc
Hardware **#A** x 8pcs

Attach cam bolts (#A) to top (#1).




Attach cam bolts (#A) to bottom (#10).



2

Part **#5** x 1pc
Hardware **#A** x 8pcs

Attach cam bolts (#A) onto both sides of divider panel (#5).




ASSEMBLY INSTRUCTIONS

3

Hardware **#F** x 2pcs

Hardware **#G** x 4pcs

Align and secure magnets (**#F**) onto divider (**#5**) by using screws (**#G**).



4


Part **#2** x 1pc

Part **#3** x 1pc

Part **#7** x 1pc

Hardware **#A** x 9pcs


Attach cam bolts (**#A**) to side panels (**#2,3,7**).



ASSEMBLY INSTRUCTIONS

5


Part #2 x 1pc
Part #4 x 1pc
Hardware #B x 2pcs
Hardware #H x 2pcs



Insert dowels (#H) to side panel (#2), then align shelf (#4) to the side panel (#2). Secure by using cam locks (#B).

6

Part #3 x 1pc
Hardware #B x 5pcs
Hardware #H x 4pcs




Insert dowels (#H) to side panel (#3), then align side panel with shelf (#2) to the side panel (#3). Secure by using cam locks (#B).

ASSEMBLY INSTRUCTIONS

7


Part **#6** x 1pc
Part **#7** x 1pc
Hardware **#B** x 2pcs
Hardware **#H** x 2pcs



Insert dowels (**#H**) to side panel (**#7**), then align side panels (**#6,7**) together. Secure by using cam locks (**#B**).

8

Part **#10** x 1pc
Hardware **#B** x 8pcs
Hardware **#H** x 8pcs




Insert dowels (**#H**) to divider (**#5**) and bottom (**#10**), then align divider and bottom to side panels (**#6,7**). Secure by using cam locks (**#B**).

ASSEMBLY INSTRUCTIONS

9

Hardware  x 4pcs

Hardware  x 4pcs




Insert dowels (#H) to divider panel (#5), then align side panels (#2,3) to the divider panel (#5). Secure by using cam locks (#B).

10

Part  x 1pc

Hardware  x 4pcs

Hardware  x 4pcs



Insert dowels (#H) to side panels (#2,3), then attach top panel (#1) to the side panels (#2,3). Secure by using cam locks (#B).


ASSEMBLY INSTRUCTIONS

11

Part #8 x 1pc

Part #9 x 1pc

Hardware #E x 12pcs




Align doors (#8,9) evenly to the unit. When securing with screws (#E), please make sure to keep the screws loose before tightening according to the even alignment of the doors.

12

Hardware #C x 2pcs

Hardware #D x 2pcs




Secure knobs (#C) to doors (#8,9) by using bolts (#D).

ASSEMBLY INSTRUCTIONS

13

Hardware  x 1set



For safety, please use the provided hardware to secure the unit onto the wall.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.


ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE



We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.