



# Instruction Manual

## 3-Way Dimmable Table Lamp Set Of 2



## Overview



## Assembly Instruction

1. Insert Harp (F) into Saddle (C).
2. Install E26 bulb (E) (not included) into socket.
3. Attach assembled Lamp shade (G) onto Harp (F) and tighten it with Finial (H).

## Product Specifications

Input voltage	120V
Rated power	100W MAX
USB port	5V 2A
Lamp socket	E26
Cord Length	5ft.

## Product Packaging

Lamp base	× 2
Lampshade	× 2
Harp&Finial	× 2
Lamp manual	× 1

## Safety Warning:

### BULB TYPE:

Use only the bulb type and wattage indicated on Wattage Label placed on or near socket.

**WARNING: NEVER EXCEED MAXIMUM WATTAGE** Indicated as bulb may cause fire.

### CAUTION:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

**DO NOT ALTER THE PLUG!**



### PROPER LAMP CARE:

Use a soft cloth to dust your lamp on a regular basis. Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

### TROUBLESHOOTING:

If fixture does not work:

1. Turn off electrical power and check all wire connections.
2. Check fuse or circuit breaker and replace if necessary.
3. Check to make sure light bulb is in working order.