
SLATE FOUNTAIN

Read the assembly instructions carefully and follow the care instructions. Save these instructions for future reference. Select a smooth, level surface to place the fountain.

Assemble components on a soft, clean surface to avoid scratching or damaging the finish.



No.	Parts	QTY.
Α	Pyramid Topper	1
в	Finger Light	1
С	Electric Submersible Pump	1
D	Basin	1
E	Pedestal Top	1
F	Pedestal Bottom	1
G	Decorative Stones	1 рк




NOTE: The water tubing is built into the pyramid topper. Take care when handling the water tube; detaching the water tube from the fountain will damage the fountain and void the product warranty.

ASSEMBLY

- 1. Place Pedestal Top (E) onto Pedestal Bottom (F).
- 2. Gently set Basin (D) onto the pedestal.
- Run Pump (C) power cord down the center of the basin, through the pedestal and under the groove in the back of the pedestal.
- 4. Connect Finger Light (B) to the short cable on the pump.
- 5. Insert the light into the underside of Pyramid Topper (A).
- 6. Connect Pump (C) to the water tube in Pyramid Topper (A) and gently place the topper onto the basin.
- 7. Gently place Decorative Stones (G) inside the basin.
- 8. Fill the fountain with enough water to keep the pump fully submerged during operation; approximately 2 gallons.
- 9. Firmly connect the AC Adapter and plug the power cord into a properly grounded GFCI outlet.

Note: When first used, there may be air in the pump. It may take several minutes for trapped air to escape, allowing water to flow.



🚹 IMPORTANT INFORMATION 🚹

USE & CARE

- · For outdoor use only.
- Check the water level frequently to ensure the pump remains fully submerged; never allow the pump to run dry as it will burn out the motor.
- Only use water in this fountain. Distilled water will help prevent mineral buildup but is not required, avoid heavily chlorinated tap water as it may damage the fountain or pump.
- Periodically change the water to reduce scale and buildup clean the fountain and pump regularly for optimal performance and appearance.

DO NOT use harmful additives such as bleach, chlorine, etc.

DO NOT use a pressure washer or abrasive materials to wash the fountain.

- Always shut off the power supply before cleaning and maintaining the fountain and the recirculating pump.
- Take care when handling the pump; only pick it up by the body of the pump, never by the power cord.
- During freezing temperatures, drain the fountain, disconnect the pump and store indoors; allowing ice to form may crack the fountain and will damage the pump.

TROUBLESHOOTING

- Ensure that the pump is fully submerged and add water to the reservoir if necessary.
- Check the pump and tubing for obstructions.
- Some splashing is normal. Check the flow control on the body of the pump; it may need to be adjusted to achieve the desired flow rate.
- If water is not flowing evenly from all tiers, the fountain may need to be leveled. Ensure the fountain is on a level surface and use shims if necessary.
- If water is not flowing within several moments of the fountain being plugged in, the pump may have trapped air which can prevent water from circulating properly. Simply unplug the power supply for a few moments and plug it back in.
- If the light is not working, ensure the adapter is fully connected and is plugged in.
- Check to make sure the power outlet is working; if in doubt about electrical connections, consult a certified electrician.

If you are still experiencing issues, please contact our customer service team through one of the methods mentioned at the top of page 1. To expedite response time, please have the item number and order information available.

Any modification or failure to follow the recommended care will void the product warranty.

MWARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.