


## WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



---

### NOTE:

---

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

---

## MAINTAINANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products, avoid exposure to rain or snow, and direct sunshine for long time. Whenever possible cover the product and/or place under patio or awnings.
- Not for commercial use, For residential use only.




Weight Limitation


**250LBS**

## PARTS LIST


Ax1



Bx1



Cx1



Estimated Duration Of Assembly

**5-10 MINUTES**

## HARDWARE LIST

Ex1  
M6x30mm



Fx2  
M6x45mm



Gx2  
M6x50mm




Hx5



Ix5



Jx1



## SPARE

Ex1  
M6x30mm



Fx1  
M6x45mm



Gx1  
M6x50mm



Hx1



Ix1




Kx1




Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.


## ASSEMBLY INSTRUCTIONS




**STEP 1:** Use bolt E, spring washer I, flat washer H, allen wrench J to connect metal leg part B and C together, don't fasten the bolt at this stage.



**STEP 2:** Use bolt F, spring washer I, flat washer H, allen wrench J to attach the Front part of the legs assembly to bottom of the seat.



**STEP 3:** Use bolt G, spring washer I, flat washer H to connect rear holes of legs with bottom of the seat. Make sure all holes on legs align with holes on bottom of seat then fasten all bolts to secure.



**Adjust levelers under legs to set the seat level.**

**STEP 4 :** Assembly completed.



**Please pay attention to the length of screws during Installation. Incorrect use of screws will lead to Instability or failure to Install.**