

# Chair Assembly Instructions


Your chair comes packaged in one box.

**DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.




Parts List		Hardware List	
<b>A</b> 1 x Back		<b>E</b> 1 x Front Rail	
<b>B</b> 1 x Left Arm		<b>F</b> 1 x Seat Cushion	
<b>C</b> 1 x Right Arm		* <b>G</b> 2 x Front Legs	
<b>D</b> 1 x Seat Deck		* <b>H</b> 2 x Back Legs	
		* <b>I</b> 4 x Washers	
		* <b>J</b> 4 x Bolts (pre-installed) M6 x 25mm	
		* <b>K</b> 1 x Hex Key M5 x 75mm	
		* Replaceable Parts	




## Assembly

### Step 3




### Step 4



### Step 5

Remove the protective fabric from the seat cushion and seat deck.



Your style may differ from images. Care for your furniture by periodically tightening all legs and periodically tightening all bolts using the included hex key.

#### About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531  
Mon-Fri 8:00am - 4:30pm CST  
customerservice@furniturequestions.com