


ASSEMBLY INSTRUCTIONS

MIRROR 2422-50

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1 We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly
 - 2 Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 - 3 Please do not over tighten screw or bolts
 - 4 Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently
- . Do not allow children to climb on furniture.
 - . Do not place television sets on top of chest, door chest, and/or dressers.
 - . Please place heaviest objects on the lowest drawers.
 - . Please have no more than one drawer open at a time.

No		Parts List	Q'ty
A		Mirror Frame	1 Pc
B		Mirror support	2 Pcs
C		Dresser	1 Pc

Hardware List Mirror (F 2422-50)			
1		Bolt (Ø1/4" x 38mm)	8 Pcs
2		Spring washer (Ø1/4"x13x1.2)	8 Pcs
3		Flat washer (Ø1/4"x19x2)	8 Pcs
4		Allen Key M4 x L100 mm	1 Pc

Remark: there is a tip restraint kit provided on the back of this product. please read the directions thoroughly and install immediately when placed in home

