

ASSEMBLY INSTRUCTIONS

PLEASE KEEP THIS FOR FUTURE REFERENCE

MODEL : ORILLIA COMPUTER DESK


1.0 hr

APPROXIMATE ASSEMBLY TIME




1 PERSON ASSEMBLY

FLOOR AREA
2.0M X2.0M



REQUIRED ASSEMBLY SPACE



AFTER SALES SERVICE

In the unlikely event of any problems with assembly, faulty or damaged parts
PLEASE DO NOT RETURN THE PRODUCT TO THE RETAILER
email us below for a prompt service.

service@mda-designs.co.uk



MDA
DESIGNS
BRINGING DESIGN TO LIFE

www.mda-designs.co.uk



Top Tips before you start!

1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your furniture, particularly items of high gloss finish, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product.
7. Do not use power tools to assemble any part of this item. Doing so can cause irreparable damage and invalidate the manufacturers warranty.



Care and Maintenance of your Furniture

- Please periodically check all fittings and re-tighten as necessary.
- Please do not sit or stand on this item.
- Never allow any kind of liquid to remain on your furniture, Absorption can cause wood to warp or finishes to de-laminate
- Please do not drag and pull your furniture.
- If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.
- Please do not place very hot or very cold items on the glass surface, unless adequately thick table mats are used to prevent such items from coming into contact with the glass.
- Please do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items.
- When cleaning glass panels use a damp cloth or chamois leather with washing up liquid or soft soap, do not use washing powders or any other substances containing abrasives as these substances will scratch the glass.
- The glass used in this product is toughened and complies with BS EN 12150-1:2000, clauses 8.3 & 8.4

Never use furniture polish on this unit.

Clean with a damp cloth & warm soapy water - never use scourers or abrasive cleaners.

PARTS LIST




HARDWARE LIST



24x
A1
CAM LOCK




24x
A2
CAM PIN



12x
B1
CONFIRMAT SCREW




8x
C
No 16 SCREW



4x
D
DRAWER RUNNER



16x
E
SCREW




4x
F
FOOTPAD





12x
B2


STEP 1




SEPARATE THE DRAWER RUNNERS




STEP 2




STEP 3



STEP 4



STEP 5



STEP 7

