


ESC0018





IMPORTANT INFORMATION

READ CAREFULLY.

KEEP THIS INFORMATION FOR FURTHER REFERENCE.

GENERAL GUIDELINES

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.

NOTES

- Please follow the assembly instructions precisely and only use the product as intended.
- If an odor is present when first opening the package, please leave the unwrapped product in a shaded and ventilated area for a few days to air out.
- Prior to assembly, please check the product for defects or missing accessories. If any defects are found or accessories are missing, do not use product as damage or injury may occur; Please contact us for assistance and replacement.
- During assembly, please only slightly tighten all screws in their correct position first, then fully tighten them. A Philips screwdriver is recommended but not included.
- It is suggested you regularly check the products bolts and connections to ensure safe use.
- Assemble the item on a soft flat and clean surface to avoid scratches and damage.
- It is recommended that two people assemble this product.

WARNINGS




- During assembly, keep parts and packaging materials away from children and pets as there could cause injury and are a potential choking hazard.
- Avoid sharp objects or corrosive chemicals to prevent damage to the product.
- Please open the item slowly and cautiously to avoid pinching your hands by metal joints, especially children.

ANTI-TIP WARNING


- Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.
- Since different wall materials require different types of fixing device, for advice on suitable fixing systems, contact your local specialized dealer.

Tools Needed



(not included)




Prepare Tools
Instead of
Coming Empty
Handed



Handle Gently












Gently Push
Against the
Wall and Do
Not Tip Over










Tips:

- If you have any further questions, please feel free to contact us via sales@homedepot.com We will reply ASAP .
- Before installation, please make sure you have all the hardware, the serial numbers are properly labeled corresponding to the list, and the quantity is correct.
- Enjoy your new purchase!






1 	2 	3  x2	4  x2
5  x2	6  x2	7  x2	8  x2


A M6*35mm  18+1PCS	B Ø15*10mm  18+1PCS	C Ø6*30mm  12+1PCS	D M6*30mm  10+1PCS
E M5*40mm  10+1PCS	F M6*45mm  4+1PCS	G 80mm  2PCS	H Ø4*10mm  4+1PCS
J M3  1PC	K M4  1PC	L M6*Ø23*15mm  4PCS	

Cam Lock Fastening System


This Cam Lock Fastening System will be used throughout the assembly process




1





A M6×35
10PCS




2










C Ø6×30
6PCS



3

A	M6*35	B	Ø15*10
			
8PCS		8PCS	




4

B Ø15*10



5PCS




5

B Ø15*10




5PCS




6

G 80mm  2PCS	H M4*10  4PCS
--	---




7




8

C Ø6*30




6PCS




9

E M7*40




10PCS

J M3




1PC




10

F	M6*45	K	M4
			
4PCS		1PC	



11

D	M6*30	K	M4
			
10PCS		1PC	



12

L M6*Ø23*15



4PCS

