


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

Tools Required for Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




1 When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2 Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3 Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4 Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5 Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6 Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.

ALL RIGHTS RESERVED.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

MD

Parts List

-  #1 x 1 pc
Headboard
-  #2 x 1 pc
Left HB Side
-  #3 x 2 pcs
Side Rail
-  #4 x 1 pc
Footboard
-  #5 x 4 pcs
Slat
-  #6 x 4 pcs
Foot
-  #7 x 8 pcs
Slat Support Leg
-  #8 x 1 pc
Right HB Side

Hardware List

-  #A x 8 pcs
Bolt 5/16"x1"
-  #B x 8 pcs
Bolt 5/16"x3"
-  #C x 16 pcs
Flat Washer
-  #D x 16 pcs
Lock Washer
-  #E x 2 pcs
Angle Bracket
-  #F x 24 pcs
Screw
-  #G x 1 pc
Allen Wrench




Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling of the product to avoid any potential injury and/or damage.



2) Align angle brackets to the HB sides (#2,8) and headboard (#1), then secure by using screws (#F). You can align angle brackets anywhere as long as it's at a lower non-visible area of the headboard. Do not align angle brackets to the bottom block of the HB sides.


1) Align and attach the metal brackets of the headboard (#1) to the HB sides (#2,8).



Turn right (clockwise) to tighten




#B x 8 pcs
#C x 8 pcs
#D x 8 pcs




#A x 8 pcs
#C x 8 pcs
#D x 8 pcs

Align side rails (#3) to the headboard (#1) and footboard (#4), then secure by using bolts (#A) with washers (#D,C).





Align the threaded end of the slat support leg (#7) with the pre-drilled holes of the slat (#5) and tighten by hand until secured. Each slat (#5) has two slat support legs (#7). Repeat the process for the remaining three slats (#5).




X 4

Turn right (clockwise) to tighten



Align the ends of the assembled slat (#5) with the pre-drilled holes on each side of the side rails (#3). Secure two screws (#F) onto each end of the slat (#5) by using a Phillips screwdriver to tighten them down to the side rails (#3). Repeat the process for the remaining three slats (#5).

Adjust the leveler according to the ground level. To lower or to raise the slat support leg, you need to turn the leveler clockwise or counterclockwise, respectively.



Turn right (clockwise) to tighten

ASSEMBLY IS COMPLETED