




IMPORTANT - The unit has a maximum loading limit of 25kg.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Operational Manual


Parts




x16 M4 x 16mm screw




x6 M4 x 25mm screw




x4 Brackets




x1 Frame



x1 Lid



x1 Large Container




x2 Small Containers




Please ensure that all the above fittings are present before installation begins.


- 1** Measure 88mm from the cabinet front face and position the frame allowing for any obstruction from above or the sides. Fit the two long screws through the central holes




- 2** Before permanent attachment to the cabinet base, fit containers and lid and test for ease of opening and container removal. Ensure the unit is clear of door hinges and other obstructions during operation. Make adjustments if necessary.



- 3** Attach the four brackets to the cabinet base using x4 short screws and x1 long screw to each bracket.



4 Fit the containers and lid



Dimensions - *maximum*

