# Assembly Instructions

Corner storage rack

If you have any issues with this product, please contact our customer service team **before returning** it.


We want you to be completely satisfied with your purchase! If anything is missing, damaged, incorrect, or not what you expected, don't worry. Please keep the outer packaging and take photos of both the packaging and products, and then reach out to us

We'll take care of everything and send you a free replacement, so you can enjoy your purchase as soon as possible without any hassle.

Assembly Instructions:

1. Carefully read these instructions and keep them for future reference.
2. Refer to the parts list for guidance and ensure that you have all the pieces before starting the assembly process, if anything is missing, damaged, incorrect, contact us FIRSTLY BEFORE assembling.
3. When assembling, place all parts on a soft, clean, and flat surface, such as a carpet, to prevent any scratches.
4. To avoid misalignment of the holes, Please don't full tighten the screws until you ensure all parts in place.

X2

When using the electric screwdriver ,
Reduce the power and torque to avoid damaging the furniture

?

✗

✔

✗

⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge.
Contach us for free replacement if having damaged or missing parts.

# Parts & Hardware List

❶ 1pc

❷ 1pc

❸ 1pc

❹ 1pc

❺ 1pc

❻ 1pc

❼ 1pc

❽ 1pc

❾ 1pc

Hardware List

A x4

B x4

C x26
M7x40mm

D x24

E x1

F x1

G x4

Installation of Cams and Pins

Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening to the hole of the pin it is locking. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.

Read each step carefully before starting. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.

① D x6

② D x4

③

D x4

A x2

④

D

D

D

D

D

A

A

F A

D

④

D x6

A x2

D

D

D

D

D

D

A

A

F A

D

⑤

B

🔩 x2

B

B

④

③

B

④

⑥

B

🔩 x2

②

B

B

B

①

B

⑥ ⑦ ⑧ ⑨

④ ③

C × 8

C

x2

⑥ ⑦ ⑧ ⑨

② ①

① ②

C × 14

C

x2

⑨

C x4

G x4

D x4

⑤

⑤

G C E D

⑩

Plastic anchor
M4x30

x4

Nylon Strap
M8x250

x2

Plastic connectors

x2

M4x30

x4

Step 1

Step 2

Step 3

Step 4