# Product Installation Instructions

A₁x1

A₂x1

Bx4

Cx2

Dx2

Ex1

Fx2

Gx1

Hx1

I x1

Jx1

Kx1

Lx1

Mx1

Nx1

Ox1

Px1

Qx1

Rx1

Sx1

Tx1

Ux1

Vx2

Wx1

Xx1

Yx1

1

Accessories list

No.	Item	Description	Quantity
①		Two In One Screw (6x28mm)	63pcs +4pcs
②		Two In One Nut (10x12mm)	63pcs +4pcs
③		Wood Chipping (6x30mm)	32pcs +4pcs
④		Handle & screw (4x16mm)	6pcs / 12pcs +2pcs
⑤		Magnetic attraction & screw (3.5x12mm)	4pcs / 8pcs +2pcs
⑥		Rubber Strip Guide & Screw (4x16mm)	4pcs / 16pcs +4pcs
⑦		Non-slip pads	6pcs +2pcs
⑧		Power Socket & Screw (3x10mm)	1pcs / 2pcs +1pcs
⑨		Fixing clip & screw (3x16mm)	10pcs +4pcs
⑩		Foot nail	4pcs +2pcs
⑪		Wire Clamp	2pcs +1pcs
⑫		Iron Bar	4pcs +1pcs
⑬		Cabinet door hinge & Screw (3x12mm)	8pcs / 16pcs +2pcs
⑭		Iron sheet & Screw (3x10mm)	8pcs / 16pcs +2pcs
⑮		Laminate support nail	4pcs +1pcs
⑯		hanger	6pcs

⑰	Anti Fall Hardware	Double-head screwdriver, use as required
	x2 / x2 (4x45mm) / x2 (3.5x14mm) / x2 / x4	1pcs

2

Product structure decomposition

3

1	⊕━━━━▭	16pcs	4	▱	2pcs	🔩	4pcs
2	🔩	16pcs					

4

Use parts ① and ②

Step1

Step2

Step3

Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign

Step 1

① ⊖━━━━▯ x4

① x4

C

5

Step 2

B x2

Step 3

D x1

6

Step 4

A₁

① x4

④ x1

④ x2

A₁

Step 5

② x8

A₁

B

D

B

**C**

x8 ②

7

Step 6

① x4

C

Step 7

B

B

C

B x2

8

Step 8

D

B

B

C

Step 9

4

x2

x1

A2

1 x4

1 x4

4 x1 x2

A2

9

Step 10

2 ×8

A2

B

D

B

C

×8 2

10

①	26pcs	⑤	2pcs / 4pcs	⑦		6pcs
②	26pcs	⑥	4pcs / 16pcs	⑧	1pcs / 2pcs	
③	16pcs					

11

Step 11

① x6

③ x4

⑥ x1
x4

x4 ③

x6 ①

G

x1 x4 ⑥

Step 12

① x2

x2 ①

H

12

Step 13

H

⑤ x1 x2

Step 14

② x2

H

x2 ②

G

13

Step 15

① x6

E

Step 16

x6 ②

F

F

E

14

Step 17

E

5
x1
x2

Step 18

E

H

x4 2

G

15

Step 19

3
x4

H
G
E

x4
3

Step 20

1
x6

6
x1

x4

1
x6

I

6
x4
x1

16

Step 21

G

H

E

I

x6 ②

Step 22

Tear off release paper and stick the black foot pad on the board

G

H

E

I

x6 ⑦

17

Step 23

3 x2

x2
3

H
I
E
G

Step 24

6 x2

x8

x2
x8
6

Step 1

Step 2

J

J

Flip the board over

18

Step 25

J

H

I

E

G

x2

x2 ②

②

Step 26

x6

③

J

H

I

E

G

③

x6

19

Step 27

K

G

H

E

I

Kx1

Step 28

L

J

H

K

I

Lx1

20

Step 29

x6 ①

O

Step 30

O

The socket cable goes through this hole

x6 ②

H

L

I

E

G

21

Step 31

x1

x2

x2

x1

8

O

I

E

G

22

①		21pcs	④	4pcs / 8pcs	⑩		4pcs
②		21pcs	⑤	2pcs / 4pcs	⑪		2pcs
③		16pcs	⑨	10pcs	⑫		4pcs
⑬	8pcs / 16pcs		⑭	8pcs / 16pcs	⑮		4pcs
⑰	x2 / x2 / x2 / x2 / x4				⑯		6pcs

23

Step 32

① x2

③ x2

⑤ x1 x2

x2 ③

x2 ①

Q

⑤ x2 x1

Step 33

The position of the hole should be back, do not reverse the installation

② x2

③ x2

x2 ③

S

Q

x2 ②

24

Step 34

1 x5

5 x1 x2

x2

1

W

5 x2 x1

W

1 x3

25

X

W

x3 ②

Step 36

② x2

W

S

Q

x2 ②

26

Step 37

③ x8

W

S

Q

x8 ③

Step 38

① x10

x5 ①

① x5

P

R

27

Step 39

W

R

S

Q

P

x10 ②

Step 40

R

W

S

Q

P

x4 ③

28

Step 41

T x1

U x1

Step 42

1 x4

29

Step 43

x4 2

30

Thread the light wire through the back panel hole

Step 45

15 x4

15 x4

W

Q

R

P

O

I

E

G

32

Yx1

W

Q

R

Y

P

O

I

E

G

33

Step 47

9 x10

W
U
T
R
L
K
I

x10 9

34

⑩ x4

Use a hammer to drive the nail into the gap of the wooden board and fix the back board

x4 ⑩

Ⓦ

Ⓤ

Ⓣ

Ⓡ

Ⓛ

Ⓚ

Ⓘ

W

U

R

T

L

K

I

36

Step 50

11 x2

11 x2

W

U

R

T

L

K

I

37

12 x4

x4 12

W

Q

P

O

A₁

A₂

I

E

G

Step 52

13 x8

x4 13

x4 13

W

Q

P

O

A₁

A₂

I

E

G

39

Step 53

4 | x1 | x2
14 | x2 | x4

x4
x2 (14)

x4
x2

(4)
x2
x1

(M)

Step 54

4 | x1 | x2
14 | x2 | x4

x4
(14) x2

(N)

(4)
x2
x1

40

Step 55

x4

x2 (14)

(4)

x2

x1

(V)

(4)		
x1		x2
(14)		
x2		x4

Step 56

(4)		
x1		x2
(14)		
x2		x4

x4

(14) x2

(V)

(4)

x2

x1

41

Step 57

W

V

V

P

O

M

E

N

G

42

Step 58

13 x16

13 x16

W

V

V

P

O

M

E

N

G

First

Second

43

Step 59

Wall Mount

Drill the hole after measuring and marking position.

Wall

Wall

Wall

17
x2
x2
x2
x2
x4

Install as required

4x45mm

3.5x14mm

17

wall

44

16 x6

16 S x6

User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller. It has 1 USB output port 1 Type-c port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn. ON/OFF the light, change light colors, and adjust the light luminance.

Operation

  This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.

B. Long touch -> adjust the luminance.

  This touch button is used to turn on/off the induction function.

A . Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B. Long touch to turn off the induction function.

C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.

 ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.

2. If you have any questions when installing, please feel free to contact us. Thank you.

Type-c output port

Light Button

USB output port

Induction Button

Socket