ASSEMBLY INSTRUCTIONS

Parts:

(2) Sides

Top - 53³⁄₁₆" x 11²¹⁄₃₂"

Bottom - 53³⁄₁₆" x 13²¹⁄₃₂"

(24) Hex Screws

Allen Wrench

(2) ⅜" Dividers

(2) ⅝" Dividers

(10) Double Hooks

(20) Small Screws

Large Back

**Phillips Head Screwdriver
(Not Included)**

(2) Small Back

Top Shelf 53³⁄₁₆" x 11²¹⁄₃₂"

Seat 53³⁄₁₆" x 13²¹⁄₃₂"

Notice - KEEP BACK GROOVES ALIGNED - Do Not Drill!

Step 1: Attach hooks to **Sides,** both side of the ⅜" **Dividers,** and both sides of the ⅝" **Dividers** by using phillips head screwdriver to screw small screws into pre-drilled holes before assembling unit. Make sure hooks are pointed upwards toward the top of the panels as seen in illustration.

Step 2: Insert edge of **Bottom** into mortise of **Side Piece**. Make sure back grooves are aligned. Insert hex screws into each of pre-drilled holes in **Side Piece**. Tighten down halfway.

Step 3: Insert edge of **Seat** into mortise of **Side**. Make sure back grooves are aligned. Insert hex screws into each of the pre-drilled holes in **Side** and tighten halfway.

Step 4: Insert edge of **Top Shelf** into mortise of **Side**. Make sure back grooves are aligned. Insert hex screws into each of the pre-drilled holes in **Side** and tighten halfway.

Step 5: Insert ⅝" **Divider** parallel to **Side**, fitting the grooves of the **Seat** and **Top Shelf**. Edge of ⅝" **Divider** should be inserted into mortise of **Bottom**. Insert hex screws into pre-drilled holes in **Bottom**. Tighten down half way. Repeat for remaining ⅝" **Divider**.

Step 6: Insert edge of **Top** into remaining mortise of **Side** panel aligning back grooves. Insert edge of each ⅝" **Divider** into the corresponding mortise on Top. Insert hex screws into pre-drilled holes of **Side** panel and tighten down half way.

Step 7: Insert ⅜" **Divider** parallel to **side**, fitting the grooves of the **Seat** and **Top Shelf**. Edge of ⅜" **Divider** should be inserted into mortise of **Top** and **Bottom**. Repeat for remaining ⅜" **Divider**.

Step 8: Slide one of the **Small Back** panels into the back grooves of **Bottom** and **Seat** until the edge rests firmly in the back groove of **Side** panel. Repeat for remaining **Small Back** panel using the **Top** and **Top Shelf** grooves.

Step 9: Slide **Large Back** panel into the back grooves of **Seat** and **Top Shelf** until the edge rests firmly in the back groove of **Side** panel.

Step 11: Finish tightening all hex screws. DO NOT OVER TIGHTEN. Stand unit upright so that it is resting on **Bottom** panel and the edges of **Side** panels. **Assembly is complete.**

Step 10: Fit remaining **Side** over edges of the assembled pieces, inserting edges of **Bottom panel**, **Seat**, **Top Shelf**, and **Top** panel into mortises of **Side** panel. Make sure that back panels fit into back grooves of **Side** panel. Insert hex screws into each pre-drilled hole on **Side** panel and tighten down half way.