





 Ax44	Bx44	 Cx12	Dx30	Ex24	Fx2
 Gx6	Hx2	Ix2	Jx16	 Kx6	 Lx2
Mx12	Nx12	Ox16	Px16	Qx4	Rx12

①x1 	②x1 	③x1 	④x1 
⑤x1 	⑥x1 	⑦x2 	⑧x2 
⑨x2 	⑩x5	⑪x3 	⑫x6 
⑬x6 	⑭x6 	⑮x6 	⑯x3 
⑰x6 	⑱x2 		

1



REPEAT for six Drawers

Connect Panel 12 to 13&14 with Hardware D
Insert Panel 15 along the slots of 13&14



x6



Fix Hardware A to Panel 11&16
Install Hardware K on 11&16 with R
Connect 17 to 12 with Hardware D
Lock Panel 11&16 to 13&14&17 with Hardware B

2

Ex12 Mx6















Stretch Hardware M and fix it to Panel 4&3 with E

3

Ex12 Mx6









Stretch Hardware M and fix it to both sides of Panel 6 with E

4

Ax4 Bx4





Connect Panel 7 to 3&6 with Hardware A&B

5

Ax2 Bx2



Connect the other Panel 7 to 6 with Hardware A&B

6





Connect Panel 4 to 7 with Hardware A&B

7



Insert Panel 8&18 along the slots of 3&6&4

8

Ax6 Bx6 Cx6 Hx6 Ix2 Qx2



Fix Hardware I to Panel 1 with Hardware H&Q
Lock Panel 1 to 3&6&4 with Hardware C&A&B(C/A first)

9

Cx6 Gx6



Lock Panel 2 to 4&6&3
with Hardware C&G© first)

10

J x 16







Connect Panel 5&9 to 2 with Hardware J

11



Install Part 10 on 5&9

12

Ox16 Px16



Lock Hardware P at 16 corners of backboard with O

13

Fx2 Lx2 Qx2



Lock the cabinet to the wall with Hardware F

14



Stretch Hardware M out

15

N x 12

X3



Fix Hardware M to drawers with N