Product Installation Instructions





Ax1



Bx1



Cx1



Dx1



Ex1



Fx1



Gx2



Hx1

Ix2



Jx1



Kx1



Lx1



Mx2



Nx2



Ox1



Px1



Qx1



Rx1

1

Accessories list

1		Three in one rod (10x38mm)	42pcs +4pcs
2		Eccen tric wheel (12x15mm)	42pcs +4pcs
3		Wood chipping (8x30mm)	28pcs +4pcs
4		Handle & screw (4x16mm)	8pcs +2pcs 4pcs
5		wine cup rack & Screw (3.5x14mm)	6pcs +2pcs 3pcs
6		Cabinet door hinge & Screw (3x12mm)	16pcs +2pcs 8pcs
7		Magnetic attraction & screw (3.5x12mm)	8pcs +1pcs 4pcs
8		Iron sheet & screw (3x10mm)	16pcs +2pcs 8pcs
9		Non-slip pads	4pcs +2pcs
10		Fixing clip & screw (3x16mm)	12pcs +1pcs
11		Wine rack	4pcs ① ② ③ 2pcs 8pcs
		AC/DC Adapter (12V⎓3.0A)	1pcs
 1pcs		Double-head screwdriver, use as required	2

Product structure decomposition



1		42pcs	5	3pcs	6pcs
2		42pcs	7	3pcs	6pcs
3		28pcs	9		4pcs



Use parts 1 and 2

Step1



Step2



Step3



Use a screwdriver to lock in the direction of the "+" sign



Disassemble along the direction of "-" sign



Step 1





Step 2

2 x2



Step 3



Step 4



2 x2

Step 5



3  x2

Step 6







Step 7

2 x2



Step 8

2 x4



Step 9

2 x2



Step 10

3 x8



Step 11



Hx1



Step 12





Step 13

2 x8



Step 14



Gx2

Insert the G board into the slot



Step 15



Insert the I board into the slot



Step 16

3 x4



Step 17





Step 18





Step 19

3 x4



Step 20





Step 21





Step 22



2 x8

Step 23



2 x6

Step 24



9



x4

Tear off release paper and stick the black foot pad on the board

Step 25



1



x4

7

x1

x2

Step 26

2 x4



Step 27

Stand up the wine cabinet



4	4pcs 8pcs	8	8pcs 16pcs	11	① 2pcs ② 6pcs ③ 12pcs
6	16pcs 8pcs	10	12pcs		
7	1pcs 2pcs		1pcs		



Step 28



Step 29



Step 30



Step 31



31

Step 32

6 x6



32

Step 33





33

Step 34



Step 35



Step 36



Step 37

6 x6



Step 38

4 x2 x4



Step 39





Step 40



Tips:











Step 41

11 x1



41

Step 42



x1



42

User's Guide

Thank you for purchasing this product. To use this product, please plug it into a 12V DC power supply. Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller with 2 touch buttons. It can turn ON/OFF the light, change light colors, and adjust the light luminance.

Product Show



ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.

Operation

This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off. B. Long touch -> adjust the luminance

This touch button is used to turn on/off the induction function.

A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 4 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B. Long touch to turn off the induction function.

C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.