




INSTALLATION

Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 64




Ø 6 x 35 mm

B x 64




Ø 15 x 9.5 mm

C x 45



Ø 4 x 35 mm

D x 61



Ø 6 x 30 mm

E x 52




Ø 3.5 x 12 mm

F x 84




Ø 4 x 12 mm

G x 14



H x 10



Ø 4 x 25 mm

I x 10



J x 4




K x 42




Ø 2.5 x 14 mm

L x 14



M x 2



N x 4



Ø 4 x 12 mm


O x 2




Q x 2




CL x 5




CR x 5



DL x 5




DR x 5



R x 10






⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:



- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*







ASSEMBLED BY 2 ADULTS

1





Screw eccentric rod(A) into plate 2 and 4 as shown.






x4

Insert wooden dowel(D) into plate 6 as shown.

2




Attach plate 6 to plate 2, put cam lock(B) into holes in plate 6 and turn clockwise to tighten as shown.





3

B x 6

 Ø 15 x 9.5 mm



Attach plate 4 to plate 6, put cam lock(B) into holes in plate 6 and turn clockwise to tighten as shown.



4


A x 4


 Ø 6 x 35 mm

E x 4




 Ø 3.5 x 12 mm

J x 1



CL x 1




Fix rail(CL) to plate 4 using screw(E) as shown. Screw eccentric rod(A) into plate 4 as shown. Fix part(J) to plate 4 using screw(E) as shown.





5



Screw eccentric rod(A) into plate 3, fix part(J) using screw(E) as shown.

Screw eccentric rod(A) into plate 5, fix part(J) using screw(E) as shown.






Then flip the plate, screw eccentric rod(A) and fix part(J) as well, fix slide rail(CR) using screw(E) as shown.



6





Insert wooden dowel(D) into plate 7 at first. Connect plate 4 and 5 with plate 7 and 37, put cam lock(B) into holes in plate 7,37 and turn clockwise to tighten as shown.






7




Connect plate 3 and 5 with plate 6, put cam lock(B) into holes in plate 6 and turn clockwise to tighten as shown.



8



Fix part(M) to plate 1 using screw(N) as shown.



9

C x 8



Ø4 x 35 mm

D x 8






Ø6 x 30 mm

E x 4




Ø3.5 x 12 mm

Q x 2



Attach plate 1 to plate 3, 5, 4 and 2 with wooden dowel(D), then fix using screw(C) as shown. Fix part(Q) to plate 1 using screw(E) as shown.




10


A x 19








E x 16





CL x 4








CR x 4





Screw eccentric rod(A) into plate 15, 13, 8 and 9 as shown.





Fix rail(CL) and (CR) to plate 8 and 9 using screw(E) as shown.





Fix slide rail(CL) to plate 10 and 35 respectively using screw(E) at first, **then flip the two plates**, fix slide rail(CR) as shown.





11





Attach plate 15 to plate 3, 5, 4 and 2 with wooden dowel(D), then fix using screw(C) as shown.



12



Attach plate 10 and 35 to plate 14 with wooden dowel(D), then fix using screw(C) as shown.



13

B x 4






Ø 15 x 9.5 mm

D x 4



Ø 6 x 30 mm



Attach plate 8 and 9 to plate 14 with wooden dowel(D), put cam lock(B) into holes in plate 14 and turn clockwise to tighten as shown.

14

B x 5




Ø 15 x 9.5 mm




D x 5





Ø 6 x 30 mm




Attach plate 13 to the base of the unit with wooden dowel(D), put cam lock(B) into holes in plate 8,10,35,9 and turn clockwise to tighten as shown.



15



Attach the component to plate 15 with wooden dowel(D), put cam lock(B) into holes in plate 9, 35, 10, 8 and turn clockwise to tighten as shown. Knock foot peg(R) into bottom.



Please note that plate 3, 9 and plate 1, 13 are not at the same height. Place a 0.6-inch plate under plate 3, 9 to prevent it from falling and cracking the holes.



16

K x 42







Ø 2.5 x 14 mm

L x 14




Fix back plate 16, 17, 18 and plank 19 using screw(K) at first. Fix each plate 17, 18 and 16 together using part(L) with screw(K) as shown.





Please note that plate 3, 9 and plate 1, 13 are not at the same height. Place a 0.6-inch plate under plate 3, 9 to prevent it from falling and cracking the holes.

17





Two people are required to lift the cabinet at the same time, otherwise the uneven force will cause the hole to split.





ASSEMBLED BY 2 ADULTS

18


C x 21

 Ø4 x 35 mm



Fix plate 27, 26 and 28 with plate 11 using screw(C) as shown.





Fix plate 27 and 28 with plate 29 using screw(C) as shown.



x4



19

Slide plate 30 and 12 along grooves as shown.






x4

20

A x 21  Ø 6 x 35 mm	H x 6  Ø 4 x 25 mm	I x 6 	
--	---	--	---

Screw eccentric rod(A) into plate 31, 33, 34, 36 and 32.
Fix knob(I) with screw(H) as shown.




21





B x 21



Ø 15 x 9.5 mm



Attach plate 32 to big drawer, put cam lock(B) into holes in plate 28, 26, 27 and turn clockwise to tighten as shown.



Attach plate 31, 33, 34 and 36 to small d rrawer, put cam lock(B) into holes in plate 28, 27 and turn clockwise to tighten as shown.


22

E x 20





Ø 3.5 x 12 mm




DL x 5



DR x 5




Fix runner(DL) and (DR) to plate 27 and 28 respectively using screw(E) as shown.



23

Align rails, slide the drawers.
Place clothing rod 20 and 21 in.




24

F x 12



Ø4 x 12 mm

G x 6




H x 2





Ø4 x 25 mm

I x 2



Fix hinge(G) to plate 24 and 25 using screw(F) as shown.
Fix knob(I) to these plates using screw(H) as shown.




25



F x 24



Ø4 x 12 mm



Attach door plate 24 to plate 4; door plate 25 to plate 5 by fixing hinge using screw(F) as shown.




26

F x 16



Ø4 x 12 mm

G x 8




H x 2




Ø4 x 25 mm

I x 2



Fix hinge(G) to plate 22 and 23 using screw(F) as shown.
Fix knob(I) to these plates using screw(H) as shown.




27


F x 32




Ø4 x 12 mm





Attach door plate 22 to plate 2; door plate 23 to plate 3 by fixing hinge using screw(F) as shown.







If doors are still not aligned if the hinges are properly correctly, please watch the video.





I




II




III





I




II




III



I




II






29

C x 2



O x 2






Install anti-tipping device as shown.

Once assembled lift furniture into place, do not drag.

Use a drill to create a small hole lining up with the top of the safety strap (M).

Fasten to wall using wall anchor (O), wall screw unit is balanced and steady before use.

You're done, enjoy.



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.