
TV Stand

Assembly Instructions - Please keep for future reference



Dimensions

Width - 69. 8inch Depth - 15. 7 inch Height - 21. 6inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture

Do not open more than one drawer at a time

Do not place heavy items in the top drawers


Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.

You will need to provide wall plugs and screws applicable for your wall type

Components - Panels

Please check you have all the panels listed below



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A	₿ 👺	©
7*39mm Cam Bolt x 37	Camlock x 37	8*30mm Wooden Dowel x 32
D	■	6
3.5*14mm Screw x 24	5*40mm Screw x 13	Strip light x 1
©	B	0
M8*30mm Screw x 4	Hex key x 1	Plastic buckle x 7
J		D
Back Panel Stiffener x 12	Hinge x 4	3.5*10mm Screw x 15
M	0	O **
Slide rail x 2	Slide rail x 2	all Fixing Pack x 2

Tools required



Phillips screwdriver (medium & large)

Ruler - Use this ruler to help correctly identify the screws


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.



Adjusting Hinges


Hinge adjustment:


a: To move the top panel up or down, loosen screws shown and move top panel to suit


b.To move the top panel in or out, loosen screws shown and move top panel to suit.


Retighten screws


C:To move the top panel left or right, adjust screws shown.
























Step 2





Fix the component (2) to the panel (1).














Insert wooden pin (C) into parts (4, 5, 6, 7). Connect parts (4, 5, 6, 7) to part (3), . then insert cam lock (B) into (4, 5, 6, 7) and lock it..


Step 12




Slide the back plate (9, 10) into the groove as shown..








Use a screwdriver to attach cam bolt (A) to part (13).







then insert the cam lock (B) into the parts (13, 14) and lock it.

14










Attach plastic wedge (J) to back panels using screws with a screwdriver.

Step 20

Step 19










Secure hinge (K) to door (11) with screws (D).

7.000mbry modadione







Secure parts (16, 17, 18, 20) with screwdriver screws.

Step 22


Step 21




Slide the back panels (19) into grooves as per diagram.




Attach cam bolt (A) to part (15) with a screwdriver.




Connect the drawer panel (15) to the drawer side panel and insert the cam lock (B) and lock it.





Step 28



Insert the drawer as shown.

Step 29

The unit is floor standing, but it is recommended that the unit is secured to the wall.

- 1. Move the unit into desired position.
- 2. Mark the wall with a suitable scribe the position of the fixing holes.



Warning: Before driling,check wall for hidden pipes and cables.

- 3. Drill holes and insert 2 x wall plug
- 4. Attach 2 x Wall Straps to to the top of the unit using 2 x Washers and 2 x Screws

