
Coffee art Machine

User Guide (V1.2)

Scan Below for Instructional
Product Video

<https://www.youtube.com/@CoffeeArtPrinter>

With any Camera APP



WISHILO



Toll free: 1-833-602-6684

SMS & WhatsApp: 1-754-364-0712

Email: wishilo@yeah.net

www.wishilo.net

Achha Technology Inc.

99 Derby St, Suite 200, Hingham, MA 02043

How to get the a Latte Art Cartridge Within Expiration Date for free?



Latte Art Cartridge

Thank you for choosing our coffee machine! To ensure your health and the best performance of the device, please note that the printer cartridges have an expiration date. Therefore, the cartridges are not included in the package with the machine. We recommend contacting us to receive a cartridge with a valid expiration date, free of charge.

You can reach us through:

Phone: 1-833-602-6684

Email: wishilo@yeah.net

Table of Contents

I Components Introduction	1
II How to get the a Latte Art Cartridge Within Expiration Date for free?	1
III Installation Guide	2
IV Latte Art Cartridge maintenance	9
V Product parameters	9
VI Special instructions	10
VII Product Warranty	13

I Components Introduction



AC01-Coffee art
Machine*1



AC02-
AC-DC Adapter*1



AC03-Camera*1



AC04-
Spare parts*1
(for backup)



AC05-Latte Art Cartridges
(not included in the package with the machine)

II How to get the a Latte Art Cartridge Within Expiration Date for free?

Thank you for choosing our coffee machine! To ensure your health and the best performance of the device, please note that the Latte Art Cartridges have an expiration date. Therefore, the Latte Art Cartridges are not included in the package with the machine. We recommend contacting us to receive a Latte Art Cartridge with a valid expiration date, free of charge.

You can reach us through:

Phone: 1-833-602-6684

Email: wishilo@yeah.net

III Installation Guide


<https://www.youtube.com/@CoffeeArtPrinter>

With any Camera APP


Scan the QR CODE for
Instructional Product Video




Step1: Take the **Coffee art Machine** out of the package and place it on the table. (Please keep the carton for transportation.)




Step2: Pull out the **fixed foam** and take the charger out. (Please keep the fixed foam for transportation)



Step3: Remove the **fixed foam** downward. (Please keep the fixed foam for transportation)



Step4: Plug in **Power cord** and **Press the power button**.



Step5: **Lift the display** from the position indicated by the arrow to the appropriate position, and then **enter the settings page**.



Step6: Connect WIFI.



Step7: Install the Latte Art Cartridge,

(The Latte Art Cartridges have an expiration date. So, the Latte Art Cartridges are not put in the package with the machine.

We would recommend that you contact us to get a cartridge within their expiration date for free.) Each cartridge can print about 1000 cups.

Take out the cartridge.




Remove the cover.




Tear off the blue ribbon.




Enter the SN code.



Open the cover.




Lift it.



Put it into the slot.



The Latte Art Cartridge installation is complete.



Step8: Scan the **QR code** to upload a picture.




Or take photos directly from the camera.




Step9: Select an image, place a **full cup** of coffee on the tray, and click "Print."

Set the image's brightness, contrast, and the size of the cup rim as needed.



Please note:



This machine has an infrared sensor that automatically detects the height of the cup. If you're using a transparent cup, make sure the drink fills the cup completely up to the rim. If the drink isn't filled enough, the infrared sensor might not work properly, causing the machine to misidentify the cup's height. This could lead to the cup tipping over, spilling liquid into the machine, and causing damage or malfunctions.



Error

(Half a cup of coffee)



Correct

(Full a cup of coffee)

IV Latte Art Cartridge maintenance

Cleaning before using : Prepare a clean, soft tissue and place it on a flat surface. Gently press the nozzle onto the tissue for 2 seconds, then clean the nozzle by moving it across the tissue. Ensure there are no visible ink stains on the tissue. Once clean, the Latte Art Cartridge is ready for use.



(1)



(2)



(3)

V Product parameters

Product model	EB-Pro
Outline size	27cm x34cm x 41cm
Net Weight	12kg
Network parameters: WiFi 802.11b/g/n	

Electric parameters	AC 100V ~240V 50/60Hz
Cup height	5cm ~ 18cm
Cup diameter	4cm ~10cm
Operating power	18W

VI Special instructions

Transportation:

1. Please ensure the fixing foam is secured in the right position during transportation.
2. Ensure all cushioning materials are properly installed to prevent transport damage.

Turn off the machine.

Lift it with your hand.



Push in the **PE foam** as shown in the picture, and **put the charger inside**.



Put the fixing foam upward.



Cautions:

- When there is an abnormal sound or collision, please turn off the appliance immediately.
- If the pattern fails to print, please stop the machine, take out the cartridge, and gently wipe the nozzle with a paper towel until the color appears.
- Please place the cup in the center of the tray so that the pattern is in the center of the cup.
- DO NOT touch the moving parts with your hands or other objects during printing to avoid being caught.

Setting:

- Printing will not be possible if the cartridge is not installed correctly.
- Please ensure the appliance is placed on a hard, flat, and level surface.

Power Supply:

- DO NOT twist or bend the power cord, as this may cause cable exposure or breakage.
- DO NOT connect the cable to an incompatible socket or other devices.
- Non-professionals are prohibited from opening the back cover for maintenance.
- If the power cord is lost or damaged, please contact customer support for a replacement.

-
- Disconnect the power before cleaning the device.

Usage Restrictions:

Do not use the appliance under the following conditions to avoid electric shock or other damage:

- Unstable locations where it may easily tip over.
- In areas with high temperatures or excessive moisture, such as a bathroom.

VII Coffee art Machine Warranty

Warranty provided by Wishilo.

Customer Support:

www.wishilo.net

Email: wishilo@yeah.net

Toll free number: 1-833-602-6684

SMS & WhatsApp: 1-754-364-0712

Warranty Coverage

STANDARD ONE YEAR MANUFACTURER WARRANTY:

- The manufacturer will offer a free firmware upgrade service for a lifetime.
- The manufacturer warrants this product (Coffee art Machine) to be free from defects in workmanship and materials, under normal residential use and conditions, for a period of one (1) Year for the original invoice date. The manufacturer agrees, at its option during the warranty period, to repair any defect in material or workmanship or to furnish a repaired or refurbished product of equal value in exchange without charge (except for a fee for shipping, handling, packing, return postage and insurance which will be incurred by the customer). Such repair or replacement is subject to verification of the defect or malfunction and proof of purchase as confirmed by showing the model number on original dated sales receipt.
- After the one (1) year warranty period expires, we will continue to provide complimentary, prompt, and effective online after-sales support. If parts replacement is required, you will be responsible for covering the cost of the new components and completing the installation.
- The manufacturer warrants the whole Coffee art Machine, including the motor, platform, electric components, and

accessories. The manufacturer cannot cover the damage to the hard case or padded soft bag resulting from normal wear. However, please note that free warranty and gifts are only available for orders placed directly with us for the Coffee art Machine.

This warranty does not include:

- Any condition resulting from other than ordinary residential wear or any use for which the product was not intended.
- Any condition resulting from incorrect or inadequate maintenance or care
- Damage resulting from misuse, abuse, negligence, accidents, or shipping damage
- Dissatisfaction due to buyer's remorse
- Damages incurred during buyer's transportation
- Normal wear and tear
- Damages incurred during assembly or maintenance
