


INSTALLATION



Product Manual

Version: 020333-01-24A-ZX




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 47



Ø 6 x 35 mm

B x 51



Ø 15 x 9.5 mm

C x 55




Ø 6 x 30 mm

D x 24




Ø 3 x 12 mm

E x 27




Ø 4 x 35 mm

F x 42




Ø 4 x 12 mm

G x 4




H x 1



Ø200 x 24 mm

I x 2




Ø26 x 20 mm

J x 4



Ø 8 x 50 mm

K x 4




Ø 6 x 50 mm

L x 4




Ø 6 x 10 mm

CL x 3




250mm

CR x 3




250mm

DL x 3




250mm

DR x 3



250mm




⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.




*This is a permanent label.
Do not remove!*



ASSEMBLED BY 2 ADULTS

1

A x 8

 Ø6 x 35 mm





Insert quickfit screw(A) into corresponding holes in plate 8 and 9 with a screwdriver as shown.

2


B x 8

 Ø15 x 9.5 mm








C x 8

 Ø6 x 30 mm




Connect plate 8 and 9 to plate 10 using wooden dowel(C) at first. Put cam lock(B) into holes in plate 10 and turn clockwise to tighten as shown.



3





180°





Fix slide rail(CR) to plate 7 using screw(D), and insert quickfit screw(A) into at first. Flip the plate, insert quickfit screw(A) as well.




4







Attach plate 14 and two plate 15 to plate 7 with wooden dowel(C) at first.
 Put cam lock(B) into holes in plate 14,15 and turn clockwise to tighten as shown.







5

A x 12  Ø 6 x 35 mm	D x 6  Ø 3 x 12 mm	CL x 3  250mm	
--	---	--	---




Insert quickfit screw(A) into plate 3 and 4 as shown.






Fix slide rail(CL) to plate 3 using screw(D) as shown.






6






Put nut(L) into holes in plate 6 at first, then insert screw(K).







Connect plate 6 to plate 23 using wooden dowel(C), put cam lock(B) into holes in plate 23 and turn clockwise to tighten as shown.



7



Attach plate 4 to plate 6 and 23 with wooden dowel(C) at first. Put cam lock(B) into holes in plate 6, 23 and turn clockwise to tighten as shown.




8

B x 2




Ø 15 x 9.5 mm

C x 8






Ø 6 x 30 mm




Attach the component (assembled in step 4) to plate 4 with wooden dowel (C), put cam lock (B) into holes in plate 14 and turn clockwise to tighten as shown.

Insert wooden dowel (C) into plate 23, 6 and 15 as shown.




9





C x 8





Ø 6 x 30 mm






Insert wooden dowel (C) into two plate 11 at first. Attach plate 11 to plate 9; attach another plate 11 to plate 4 and 8 as shown.





10






Attach plate 3 to plate 23, 6 and 15, put cam lock (B) into holes in plate 6, 23, 15 and turn clockwise to tighten as shown.



11




Insert wooden dowel (C) into plate 3, 4, 7, 8, 9 and 23 as shown.




12



E x 15



Ø 4 x 35 mm




Cover plate 16 to the component and fix using screw(E) as shown.








13

A x 8



Ø 6 x 35 mm



Insert quickfit screw(A) into corresponding holes in plate 2 as shown.


14

B x 8




Ø 15 x 9.5 mm




C x 8






Ø 6 x 30 mm




Insert wooden dowel(C) into plate 3,7,8 and 9 as shown.
Cover plate 2 to the top of the unit,
put cam lock(B) into holes in plate 3,7,8,9 and turn clockwise to
tighten as shown.



15




Fix plate 17 and
18 to plate 19
using screw(E)
as shown.





16



Slide plate 20 along
grooves as shown.





17





Insert quickfit screw(A) into plate 21 and 22 as shown.





18







Attach plate 21 and 22 to plate 17, 18 respectively, put cam lock(B) into holes in plate 17,18 and turn clockwise to tighten as shown.




19




Fix runner(DL) and (DR) to plate 17 and 18 respectively using screw(D) as shown.



20



Slide drawers into corresponding positions.





21

F x 8





Ø 4 x 12 mm

G x 4



Fix hinge(G) to plate 12 and 13 using screw(F) as shown.



22



F x 16




Ø 4 x 12 mm



Attach plate 12 to plate 4; plate 13 to plate 3 by fixing hinge using screw(F) as shown.








If there is misalignment after you install,
adjust the screw to the best condition

If doors are still not aligned if the hinges
are properly correctly, please watch the video.


<https://youtu.be/n0Lb36SoODM>





I




II




III





I




II




III



I




II




24

A x 3







Ø6 x 35 mm

J x 2



Ø8 x 50 mm



Insert quickfit screw(A) and wooden dowel(J) into corresponding holes in plate 1 as shown.

25



B x 3




Ø15 x 9.5 mm




Attach plate 5 to plate 1, put cam lock(B) into holes in plate 5 and turn clockwise to tighten as shown.







26



Fix part(H) to plate 1 and 5 using screw(F) as shown.



27



Put nut(L) into plate 2 at first, then insert quickfit screw(K) into plate 2 as shown.

Connect plate 1 to plate 2 using wooden dowel(J), put cam lock(B) into holes in plate 1 and turn clockwise to tighten as shown.

28

F x 8




Ø4 x 12 mm

I x 2



Ø26 x 20 mm



D




Ø3 x 12 mm

F



Ø4 x 12 mm

Fix plate 1 to plate 4 together using part(I) with screw(F) as shown.



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT



0000 0000000000 0 0 00000 0



000000000000