


MANUAL INSTRUCTION

Wooden Well Planter



We offer a diverse range of products to meet the needs of customers.

Outdoor Furniture

We are a professional furniture provider with top-notch factories and outstanding designs, Our mission is to provide consumers with new lifestyles. By collecting consumer feedback, we constantly improve our products and create more choices for consumers. If you want to create your space, We are an ideal choice.

Always.



WARNING

Ensure that all parts
and hardware are
available before
beginning assembly

I TOOLS REQUIRED



Leveler(Optional)



Phillips Screwdriver



1 Persons Assembly



Up to 45 Minutes For Assembly

PARTS

A

PLANTER WALL



24 PCS

B


PLANTER WALL LOCK



8 PCS

C


UPPER POST



2 PCS

D


LOWER POST



2 PCS

G


ROOF SUPPORT



2 PCS

E


SUPPORT BEAM



1PCS

F


BUCKET REST



1 PCS

H

ROOF



1 PCS

I


BUCK



1 PCS

J

fasten batten




4 PCS

HARDWARE

1

M6 X 55MM BOLT SET



8 PCS

2

M3.5 X 25MM SCREW



6 PCS

3

M3.5 X 40MM SCREW



10 PCS

4

M3.5 X 30MM SCREW




32 PCS+2PC

PRODUCT ASSEMBLY

- 1

Interlock six part A planter walls into a semi-circle.

PART	NO.	QTY.
	A	6





PRODUCT ASSEMBLY

2

Close the circle with two part B planter wall locks. Repeat steps 1 and 2 to build additional three planter walls. Securely stack the walls on top of one another.


NOTE: Arrange the walls so there are no gaps or uneven spaces.

PART	NO.	QTY.
	B	2



3

Attach two part C upper posts to two part D lower posts with four part 1 bolt sets.



PART	NO.	QTY.
	C	2
	D	2


PART	NO.	QTY.
	1	4

PRODUCT ASSEMBLY

4

Attach part E support beam with two part 3 screws. Attach the part F bucket rest with two part 2 screws. Attach two part G roof supports with four part 1 bolt sets.

PART	NO.	QTY.	PART	NO.	QTY.
	G	2		1	4
	E	1		2	2
	F	1		4	2




PRODUCT ASSEMBLY

5

Place the assembled posts inside the planter wall assembly. Attach the two posts with eight part 3 screws.

NOTE: Use a leveler to ensure the posts are attached at the correct angle.

PART	NO.	QTY.
	3	8




PRODUCT ASSEMBLY

6

Please stick 4 part J to the bottom of the wishing well with screw #4.


PART	NO.	QTY.
	4	32



PRODUCT ASSEMBLY


- 7** Place part H roof on top of the roof supports and secure with four part 2 screws. Tie the part I bucket to the support beam.

PART	NO.	QTY.	PART	NO.	QTY.
	H	1		2	4
	I	1			




HELP CENTER


Question about your product? We're here to help. Visit us at:




Chat Support




Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

We Stand Behind the Quality of Their Furniture

If you have any issues with your item please let us know! We will always do our best to come up with a solution that you will be happy with. Please get in touch with our customer service team before returning the product.

And pls do not throw the original box(es) if you have not finished assembling or confirmed no quality issues.

Length of return period:

Items can be returned within 30 days of purchase. In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

1. Your item has a manufacturing defect in its materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after photos are sent.
2. Your item has been damaged in transit. For example, glass is broken or wicker is damaged. We will send you a prepaid shipping label after photos are sent.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after photos are sent of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

Return Request

In order to get a full refund as described in this return policy, all items must be:

(1) In a brand new/unused condition, please provide photos before and after packaging.

(2) When returning, all accessories and parts are firmly packed in all original packaging.

If your return does not meet the requirements, you may not get a full refund.

When will I be refunded? The refund is released once the goods have been returned to our warehouse. What if the product is damaged/defective outside of the valid return period? We want you to be a happy customer.

Please reach out to us by email and we will come up with a solution to make sure you are satisfied.