

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.



PART LIST

When unpacking, please carefully not to discard any parts with the packaging. Before continuing, please make sure you have all of the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
А	Тор	1		В	Bottom Shelf	1	
С	Side Frame	2					


HARDWARE LIST

When unpacking, please carefully not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Bolt (Móx35mm)	12	0	2	Flat washer (Ф6.5x 13mm)	12	\bigcirc
3	Lock washer (Ф6.5x 11mm)	12	\bigcirc	4	Allen Key (4 x 80mm)	1	

STEP 1

Attach side frame (C) to the top (A) with bolt (1), washer (2) and (3) as shown below. Tighten with allen key (4).



STEP 2

Attach Bottom shelf (B) to side frames (C) with bolts (1), washers (2) and (3) as shown below. Tighten with Allen key (4).

