
# **Assembly Instructions**

Caution: You must read this before you proceed

# **Dining Chair**




Noble house Home Furnishings LLC

Parts List			
Label	Picture	Description	QTY
А		Chair Back	1
В		Chair Seat	1
С		Front Leg	2
D		Arm-Left	1
E		Arm-Right	1
Hardware			
Label	Picture	Description	QTY
1		Bolt (M8*50mm)	4
2		Bolt (M8*65mm)	5
3		Bolt (M8*80mm)	5
4		Spring Washer (M8)	14
(5)		Flat Washer (M8)	14
6		Bolt(M6*45mm)	3
7		Spring Washer(M6)	3
8		Flat Washer(M6)	3
9		5mm Allen Wrench	1
100		4mm Allen Wrench	1
(11)	Noble house Home Fur	Plug	2

Noble house Home Furnishings LLC

# Assembly Preparation

Before Beginning Assembly:





- Read instructions, cover to cover-
- **†**2x**†**
- Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-


## Assembly Steps

#### Overview



This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly


#### Step 1



REMOVE the Seat Base Cover from the Chaire Seat(B), take out the front legs(C).

Place all the parts on a clean, non-marring surface..

#### Step 2




You will now have the Chair Seat bottom (B) and the Front Legs(C) facing upwards.

Insert the Front Leg(C) completely vertical into seat frame conner by using 4 Bolt 65mm(2) + 4 Spring Washer(4) + 4 Flat Washer(5) and the Allen Wrench(9).

At this point in the assembly.DO NOT fully tighten the connections.

#### Step 3



Place the Chair Back(A) on a clean, non-marring surface.

Align the mounting positions on the Seat(B) to the mountings on the Back with Legs(A).

Lock the middle mounting position, by using 1 Bolts 50mm ①+1 Spring Washers ④ and 1 Flat Washers ⑤ with Allen Wrench ⑨.


Lock the corner four mounting positions and attach them using 4 Bolts 80mm@+4 Spring Washers@ +4 Flat Washers® with Allen Wrench®, as shown on the picture above.

#### Frendly notice:

If the mouonting positions cannot be aligned well which hinders the installation, then sway the Seat(A) lightly when locking the Bolts, this action could help avoid the Bolts getting stuck and ensure assemble smoothly.

Do not fully tighten the Bolts.

#### Step 4



Position the Chair Back(A) as shown in the picture.

Align the mounting positions of the Arm(D&E) with the Chair Back(A)

Backrest position: 2 Bolt 45mm@ + 2 Spring Washer@+ 2 Flat Washer®

and the Allen Wrench. Press the Plug 1 into the position


Seat frame position: 2 Bolt 50mm①+ 2 Spring Washers④+ 2 Flat

Washers and the Allen Wrench .

Repeat the same process with the Right Arm(E).

Note: Do not fully tighten the Bolts.

### Step 5



Noble house Home Furnishings LLC

Place the Chair on a level Surface to check for wobbles.

If it wobbles, lift the Chair some 30cm to 50cm high from the ground.

Keep your feet and toes well away from the drop zone.

Drop Chair freely and vertically, with all four legs hitting the ground at the same time.

This Drop Test will help to ensure that all Bolts and gaps reach full alignment status.

Test again for evenness on a Level Surface.


If no wobbles are found, proceed to tighten all the Bolts.

When tightening the Bolts, tighten sequentially.

Do not fully tighten any Bolt fully and then move on towards the next one. This may cause the frame to warp.

If there is still wobbles, loosen the Bolts and execute this same drop test.


#### Step 6



Place the Seat Base Cover back as shown in picture.

Smooth the Magic Tape down, Make sure all parts are connected and securely locked into position.

#### Step 7



Your Chair is ready for use.

This Arm Chair can only be used on a flat, level surface.

### Care & Maintenance



Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



Not for commercial use. For residential use only.





Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.