

INSTRUCTIONS FOR USE OF YOUR ROPE HAMMOCK AND STAND

This Carton Contains:

- A. 1 Cotton Rope Hammock with Chains Attached
- B. 1 Hammock Frame
 1. 2 foot brackets
 2. 2 long beams with s-hooks attached
 3. 1 short beam (no hooks)
 4. End caps are included and may already be attached to the foot brackets and beams.

Assembly Instructions (no tools required):

1. Place the short beam on the ground and insert a foot bracket onto each side.
2. Insert the long beams onto the foot brackets facing upward. Make sure the ends with the s-hooks are on the top and facing inwards toward each other.
3. Hook the hammock to the S-hook on each side of the frame.
4. Take extreme care when entering the hammock for the first time. If the hammock goes to the ground, exit the hammock and tighten up the chain. Repeat this until you find a comfortable height.

NATURAL DEFECTS OF WEATHERING FROM SUN AND RAIN EXPOSURE:

All hammocks deteriorate over time with exposure to the elements. As a result, they should be regularly inspected and replaced periodically to ensure safety.

Cotton: Fibers will darken to a gray color, as fibers breakdown, strength will be lost. If not allowed to dry thoroughly, mold or mildew will result.

Wood: Wood spreader bars on hammock will become bleached and may turn gray. Varnish finish may wear off surface.

Important Information:

When you open your hammock, it may have become distorted or have gaps in the bed due to packaging. Do not be alarmed, this is normal. Hang the hammock up and simply brush your hands across the weave to straighten it out. Due to a built in stretch factor, you may have to adjust the tension in the hammock several times. It will stretch to its desired length after continued use.

Precautionary Measures:

- Check for loose or untied ropes.
- Fraying at possible wear points:
 - Where the ropes pass through the wooden spreader
 - Around the metal ring at each end of the hammock
 - Where the ropes intersect in the body/hammock bed.
- Weak and fraying ropes: Check ropes by pulling on them. If ropes are weak, the hammock may be unsafe for further use.
- Cracks or weak areas in the wood.
- Keep hammock out of direct sunlight and rain whenever possible.
- Make sure your stand is properly assembled using these instructions before attaching hammock to stand. Check the assembly of the frame prior to each use. Make sure the larger pole fits all the way over the small pole before each use.

These precautionary measures are especially important before hanging your hammock each season and before storing it away.

Warnings:

- Maximum weight capacity is 275 lbs. **NEVER** exceed weight capacity.
- Children should not use the hammock without adult supervision.
- Always inspect the hammock and ties carefully before each use.
- Examine the entire hammock for wear to avoid accidents.
- Hammocks are designed for leisure and relaxation. It should not be used as a toy or a swing. Do not stand in the hammock at any time.
- Your hammock is made of the highest quality twisted cotton rope. Your hammock's worst enemies are rain, sun and heat. To prolong the life of your hammock, store it in a safe dry place when not in use. You may also choose to purchase a hammock storage bag, cleaner and protective shield to prolong the life of your hammock.
- Check for excessive rust periodically during the usage season.

For Customer Service, please contact: