

1. Seat Height Adjustment

To increase the height, lighten the load on the seat and lift lever. Increase the load on the seat and lift lever to lower seat height.

Lever Location: Right hand while sitting.

2. Back Rake Adjustment

To free float or to adjust the back angle, lift the lever up and apply pressure to the back of the chair.

Select the required position and push lever down to lock.

Lever Location: Left hand while sitting.

3. Seat Tilt & Back Rake Adjustment

To free float or to adjust the seat & back angle, lift the lever up and apply pressure to the back of the chair. Select the required position and push lever down to lock.

Lever Location: Left hand while sitting

4. Body Weight Adjustment

To decrease the body weight tension turn knob clockwise. To increase tension, turn the knob anticlockwise

