

AIR FRYER / QUICK START GUIDE

THANK YOU FOR PURCHASING YOUR NEW COSMO AIR FRYER
(PLEASE DO NOT RETURN TO THE STORE)

If you have questions, please call the experts.
HELP LINE: 1-888-784-3108 or Visit: www.cosmoappliances.com

IT IS RECOMMENDED TO LET THE AIR-FRYER HEAT FOR ABOUT 5 MINUTES WITHOUT ANY FOOD IN IT.

GETTING STARTED:

1. PLUG IN

Plug the unit into a U.S standard 120-volt electrical outlet.

2. PUT THE AIR FRYER IN A SAFE LOCATION

Place the fryer on a stable, horizontal, level heat-resistant surface 6 inches away from other objects. Load food into basket and put basket in pan and insert into unit until it locks into place.

3. TURN ON


Press the PUSH button and access desired controls

4. Manual OPERATION

- A) Press the Temperature / Timer button and use the knob to manually adjust the cooking temperature/time.
B) Press the PUSH button to start cooking.
C) Press the Warming button to keep food warm for up to 120 minutes.
-Press the Clear button if you need to reset or stop.

5. PRESET OPERATION

- A) Press the Menu button and use the knob to scroll through the Preset Cooking Temperatures and Times:



Fries

390°/20 min



Ribs

360°/15 min



Shrimp

320°/20 min



Cake

320°/40 min



Drumstick

360°/25 min



Meat

320°/20 min



Fish

360°/20 min

B) Press the PUSH button to start cooking.

C) Press the Warming button to keep food warm for up to 120 minutes.

COMMON PROBLEM SOLVING

PROBLEM	CAUSE	SOLUTION
Does Not Work	● Power cord has not been inserted into The power socket	● Closely insert the power cord into the grounded power socket.
See Product Manual for full list of Troubleshooting tips	● Did not press the PUSH button to begin cooking.	● Press the PUSH button to begin cooking.
	● Did not set the cooking mode	● Set desired temp and time before pressing PUSH to begin. Choosing a Preset from the Menu button will use a predetermined temp / time.