



Assembly instruction



TV-Stand

VIPService68@outlook.com

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware, If Parts are missing defective or having wrong parts in package, or Board Surface is broken, scratched or lack of some screw holes. You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
- ✓ Give yourself enough room for the assembly process
- ✓ Caution: If using a power drill or power screwdriver for screwing, please pay attention to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: 2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Do not make the screws too loose or too tight.
- The accessory bag contains some small accessories, which should be kept away from children.
- The remaining parts are spare parts.
- Do NOT use harsh chemicals or abrasive cleaners on this item. And Never push, pull, or drag your furniture.
- Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit (I#Accessories) to prevent the unit from tipping, causing any accidents or damage. the tipping restraints are intended only as a deterrent, they are not a substitute for proper adult supervision.



Product Installation Video


Please scan this QR code with your cell phone YouTube to watch the installation video instantly.






















Contact Us

When missing parts? Or feeling stuck? you can contact us by scanning the QR code below or via after-sales email (VIPService68@outlook.com), we will reply you in time.







<p>A</p>  <p>8PCS</p>	<p>B</p>  <p>8PCS</p>	<p>C</p>  <p>20PCS</p>	<p>D</p>  <p>14PCS</p>	<p>E</p>  <p>8PCS</p>
<p>F</p>  <p>2PCS</p>	<p>G</p>  <p>12PCS</p>	<p>H</p>  <p>2PCS</p>	<p>I</p>  <p>2PCS</p>	<p>J</p>  <p>4PCS</p>
<p>K</p>  <p>4PCS</p>	<p>L</p>  <p>4PCS</p>	<p>M</p>  <p>20PCS</p>	<p>N</p>  <p>2PCS</p>	<p>O</p>  <p>1PC</p>
<p>P</p>  <p>1PC</p>	<p>Q</p>  <p>2PCS</p>	<p>R</p>  <p>1PC</p>	<p>S</p>  <p>1PC</p>	

STEP 1



Preparation before installation

- Please apply wax evenly in the grooves of Panel No 1 and Panel No 10. This will help the cabinet door slide out more smoothly.




S*1

STEP 2 First, insert 4Pcs No. C wooden dowels into the holes on the side of Panel No. 9, and then use 4Pcs No. D screws to connect Panel No. 3 and Panel No. 4 to Panel No. 9.



The side with round holes on Panel No. 3 and Panel No. 4 should face outward.



The side of Panel No. 9 without pre-drilled holes near the socket holes should face downward.




C*4



D*4

STEP 3 First, insert 8Pcs No. C wooden dowels into the corresponding holes of Panel No. 2, Panel No. 3, Panel No. 4, and Panel No. 5, and then use 8Pcs No. D screws to connect them to Panel No. 10. (Before installing Panel No. 10, please check if its groove has been lubricated with No. S wax block. If not, please refer to step1.)




C*8




D*8

STEP 4 Use 20Pcs No. M screws to install the No. L metal plate on Panel No. 10.




STEP 5 First, install the No. N adjustment foot screws to the No. 12 support legs, and attach the No. 12 support legs to the No. 10 panel. Then, attach the No. J anti-skid pads to the bottom of the No. 11 support legs. Finally, install the four No. 11 support legs onto the No. L metal plate.




STEP 6

Insert Panel No. 6 and Panel No. 8 into the corresponding grooves, and then insert 8Pcs No. C wooden dowels into the corresponding holes of Panel No. 2, Panel No. 3, Panel No. 4, and Panel No. 5.





STEP 7

Use 2Pcs No. Q screws to attach the power strip to Panel No. 9. If Panel No. 9 does not have pre-drilled holes, please check if it is installed upside down.



STEP 8


Install 8Pcs No. A screws in the corresponding holes on Panel No. 1. (Before installing Panel No. 1, please check if its groove has been lubricated with No. S wax block. If not, please refer to step1.)



A*8

STEP 9




Use 8Pcs No. B screws to connect Panel No. 1 to the cabinet.



B*8


STEP 10

Use 12Pcs No. G screws to install the back panel buckle in the positions shown in the picture. After installation, the cabinet will be more stable. Please make sure to install it. (The indicated positions are not pre-drilled.)



STEP 11


First, insert 8Pcs No. E shelf supports into the holes of Panel No. 2, Panel No. 3, Panel No. 4, and Panel No. 5 (you may choose different hole positions based on the height of the items to be stored), and then place Panel No. 7 on the shelf supports.



E*8

STEP 12

Use 4Pcs No. K screws to install the No. F handle on Panel No. 13.




F*2



K*4


STEP 13

Insert the No. 13 sliding door through the groove at the back of the cabinet into the groove on the left side (from the rear view). Make sure insert the side with the handle into the groove first.





STEP 14

Insert the No. 13 sliding door through the groove at the back of the cabinet into the groove on the right side (from the rear view). Make sure insert the side with the handle into the groove first.




STEP 15




If the TV cabinet is unstable on the ground, please rotate the No. N adjustment foot pad on the No. 12 support leg.

STEP 16


Install the anti-tip device to secure the cabinet to the wall. This helps prevent tipping, especially in households with children.




First fix the anti-rewind screw in the reserved hole of the product.




then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.




Then use a tape drill to make holes in the wall that are suitable for the product screws.






Then, put the expansion bolt into the hole



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.



-  **D*2**
-  **H*2**
-  **I*2**

Care Instructions



Your furniture, if treated with respect and love, will last you a long time. Each piece requires light maintenance to maximize its longevity.

Few quick tips before using this product

1. Recommended weight limit for the table top is 220lbs and 55lbs for each Shelves.
2. After waxing the cabinet, you may notice some small particles falling when opening or closing the doors. This is normal and should disappear after some use.
3. When storing heavier items, place them as close to the bottom storage area as possible to maintain stability.
4. Check and tighten the camlock and screw periodically as it may loose over the time.

How to take care of it?

1. Avoid direct sunlight or use curtains or blinds to limit the sun exposure to the product.
2. Clean the product regularly with a dry, soft cloth.
3. Avoid using abrasive or liquid cleanser.
4. Avoid placing hot objects onto the table top surface.
5. Spillage may damage the surface. Clean immediately with a dry cloth.
6. We recommend using placemats or coasters underneath glasses, cups, bowls or plates to prevent scratches to the table surface.

Frequently Asked Questions



For any enquiries or issues regarding your purchase, chat with us at VIPService68@outlook.com

1. What should I do if my order is incomplete?

Our products ship flat-packed in separate boxes. When your order leaves via FedEx, you 'll get an email with tracking details. Keep in mind that FedEx may deliver your boxes separately, so wait until you have them all before you start assembling. If you need help tracking your delivery, please visit aftersaleservice.net or email vipservice68@outlook.com.

2. What should I do if my shipment is damaged or items are defective?

We 're really sorry if you received a damaged or defective item. Please email us at vipservice68@outlook.com or chat with us at aftersaleservice.net. Send a description and some photos or videos of the damage, and we 'll sort it out as quickly as possible.

3. Can I order replacement parts?

Yes! Just get in touch with our customer service at vipservice68@outlook.com or via chat at aftersaleservice.net. Tell us your order ID, and we 'll help you with the parts you need.1

4. What warranty do you offer?

Our warranty covers damage that isn 't caused by user error. If your product is damaged for these reasons, keep it and send us some photos at vipservice68@outlook.com. We 'll review the damage within 24 hours and work for you to find a solution.

5. Why is my cabinet door not sliding smoothly and feels a bit stuck?

Ensure that the grooves on Panel No. 1 and Panel No. 10 are properly lubricated with No. S wax during installation for smoother door movement. Additionally, after regular use, the door will become smoother over time.

6. Why does the new furniture have an odor?

A slight smell is normal with new furniture due to the materials and packaging. It should fade away after a few days of airing out.

7. Why is there a slight color difference in my furniture?

The color may appear different under varying lighting conditions and display settings. In dim lighting, the wood grain may look darker. This is completely normal and just part of the natural characteristics of the material.

8. My furniture seems smaller than expected. What should I do?

Our product dimensions are accurate. Pictures often focus closely on the item, which can make it appear larger than it really is. When placed in a bigger room, the furniture might seem smaller. Room layout and screen settings can also affect your perception of size. If you have any concerns or need more details, please contact our customer service at aftersaleservice.net or email vipservice68@outlook.com. We're here to help!

9. What should I do if I want to return the product?

We offer a 30-day return policy from when you receive your order. To start a return, please contact us through Amazon, email vipservice68@outlook.com, or visit aftersaleservice.net. Just let us know why you 're returning the item, and we 'll help you out.