



ESD-400 Deck-Mount Foam Soap Dispenser



CLEANING FOAM SOAP DISPENSER

If the tip of the soap nozzle is clogged, the dispensing capability may fail or function partially. Clean the nozzle according to the following procedure:

- Press the operation switch to OFF (the operation light goes off).
- Remove the nozzle using a 2.5 mm Hex key. Next, remove the internal mesh. Wash it with lukewarm water.
- Insert the mesh and then the nozzle back into the spout and tighten with the hex key.
- Turn ON the operation switch (the operation light goes on). Check the foam soap spraying state.
- Repeat as needed



TROUBLESHOOTING GUIDE

1. Unit does not operate.

Check operation switch is on.
Check power plug is securely inserted to the outlet.

2. Soap does not dispense.


Soap bottle needs replacing.
Check soap dispensing nozzle for clog.
Clean hand sensor.

3. Liquid soap is not in foam state.

Check mesh is mounted in the foam-dispensing nozzle.

MESH REPLACEMENT KIT

1. Replacement mesh w/ o-ring
2. Hex key



When assistance is required, please contact
Sloan Technical Support at: 1-888-SLOAN-14 (1-888-756-2614).