

#3505 Toscano Fountain



Items Required For Assembly

Submersible Pump	(provided)
Vinyl Tubing	(provided)
Rubber Stopper	(provided)
Silicone Sealer	(provided)



- 1) Place base (A) on a firm, level surface. Lift up one side of the base approximately 3" by placing some wood under the base where the groove is located.
- 2) Place bowl (B) onto the base (A).
- 3) Place pump in the bottom of bowl (B). Pass the electrical cord through the PVC coupling at the bottom of the bowl, through the base, and out the bottom of the base where the groove is located.
- 4) Remove the wood holding up the base (A) and gently lower the base to the ground.
- 5) Pull the electrical cord out the bottom of the base so that approximately 6" remains inside the bowl (B).
- 6) Take the rubber stopper and apply silicone sealer in the center hole. Open the stopper and place around the electrical cord. Apply silicone sealer around the outside and along the inner cut of the stopper and insert fully into the PVC coupling at the bottom of the bowl.
- 7) Pour a small amount of water into the bowl (B) so that the rubber stopper is submerged. Check to make sure that the water is not leaking through the rubber plug. If you find water is leaking, remove the rubber plug, and return to step 6.

- 8) Place the pumphouse (C) over the pump.
- 9) Screw the Hose Barb into the threaded coupling at the bottom of the small bowl (E). This may have been pre-installed at the factory.
- 10) Attach one end of the vinyl tubing to the hose barb at the bottom of the small bowl (E).
- 11) Place the small bowl (E) onto the pumphouse (C) so that the vinyl tubing extends through the pumphouse to the pump.
- 12) Through the access cutout, attach the free end of the vinyl tubing to the outlet of the pump. Make sure that the tubing is not kinked so as to restrict water flow. You may cut the vinyl tubing if necessary.
- 13) Place the finial (F) into the top bowl so that the hole at the bottom of the finial is above the water outlet at the bottom of the small bowl (E). Once the fountain is running the water pressure will push the water through the finial without excessive splash. For more water flow out of the finial, push a small length of vinyl tubing into the bottom of the finial so that it extends out approximately 1/2". This vinyl extension will allow a more direct connection to the water outlet at the bottom of the small bowl (E).
- 14) See diagram below for placing clear silicone sealer along the bottom rim of the small bowl (E) under the water chutes in order to maximize the drip action over the edge of the bowl. This may have been already done at the factory.
- 15) Fill the large bowl (B) with water so that the pump is completely submerged.
- 16) Plug the pump into a GFCI protected outlet.
- 17) Adjust the water flow of the pump if necessary using the flow control dial on the pump. Add water to the fountain as necessary.
- 18) If necessary, use the breakaway shims between components to fine tune the level of the bowls.
- 19) Place the access door (D) into the access cutout of the pumphouse (C) and enjoy your new fountain.

NOTE: To maximize the drip action over the spillways, place a bead of clear silicone sealer along the bottom lip of each spillway. This will create a "low point" from which the water will be forced to drop.

