


# **INSTALLATION**

## *Product Manual*



### **IMPORTANT INFORMATION!**

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.



### **AVOID SCRATCHES!**

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



### **IMPROVE EFFICIENCY !**

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



### **ANTI-TOPPLE WARNING !**

Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

### **IMPORTANT !**





It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 158




Ø 6 x 35 mm

B x 158



Ø 15 x 9 mm

C x 40




Ø 8 x 30 mm

D x 168




Ø 3 x 12 mm

E x 20




Ø 4 x 35 mm

F x 82



Ø 4 x 30 mm


G x 2



H x 1



J x 4




Ø 4 x 12 mm

K x 4




CL x 16




350 mm

CR x 16




350 mm

DL x 16




350 mm

DR x 16



350 mm




## ⚠ WARNING



**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



*This is a permanent label.  
Do not remove!*




ASSEMBLED BY 2 ADULTS





1




Screw eccentric rod(A) into board 1 as shown.







2








Screw eccentric rod(A) into board 2 and 3 as shown.




3



<p>D x 48</p>  <p>Ø 3 x 12 mm</p>	<p>CL x 8</p>  <p>350 mm</p>	<p>CR x 8</p>  <p>350 mm</p>	
--	---	---	---

Fix rail(CL) and (CR) to board 2 and 3 with screw(D) as shown.




# 4






A x 14  
  
 Ø6 x 35 mm





Screw eccentric rod(A) into board 5 and 29 as shown.




# 5

<p>A x 7</p>  <p>Ø6 x 35 mm</p>	<p>D x 24</p>  <p>Ø3 x 12 mm</p>	<p>CL x 4</p>  <p>350 mm</p>	<p>CR x 4</p>  <p>350 mm</p>	
--	---	---	--	---



Fix rail(CL) and (CR) to board 4 with screw(D) as shown.  
Flip to back, screw eccentric rod(A) into as shown.



6





Fix rail(CL) and (CR) to board 28 with screw(D) as shown.  
Flip to back, screw eccentric rod(A) into as shown.



7



Attach board 5 to board 4 using wooden dowel(C), add cam lock(B) into board 5 and turn clockwise to tighten as shown.



8

B x 5




Ø15 x 9 mm




C x 5






Ø8 x 30 mm




Attach board 4 and 5 to board 2 using wooden dowel(C), add cam lock(B) into board 4,5 and turn clockwise to tighten as shown.



9



Attach board 9 to board 2, add cam lock(B) into board 9 and turn clockwise to tighten as shown.





# 10

B x 6









Ø15 x 9 mm



C x 5



Ø8 x 30 mm



Attach board 3 to board 9, 4 and 5 using wooden dowel(C), add cam lock(B) into board 9,4,5 and turn clockwise to tighten as shown.



# 11

B x 3









Ø15 x 9 mm



C x 2



Ø8 x 30 mm



Attach board 29 to board 28 using wooden dowel(C), add cam lock(B) into board 29 and turn clockwise to tighten as shown.



# 12

B x 5




Ø15 x 9 mm




C x 5



Ø8 x 30 mm



Attach board 28 and 29 to board 2 using wooden dowel(C), add cam lock(B) into board 28,29 and turn clockwise to tighten as shown.




# 13



B x 1



Ø15 x 9 mm



Attach board 9 to board 2, add cam lock(B) into board 9 and turn clockwise to tighten as shown.



# 14

B x 6




Ø15 x 9 mm




C x 5



Ø8 x 30 mm




Attach board 3 to board 9, 28 and 29 using wooden dowel(C), add cam lock(B) into board 9,28,29 and turn clockwise to tighten as shown.






# 15


A x 8  
  
 Ø6 x 35 mm




Screw eccentric rod(A)  
 into board 8 as shown.





# 16

B x 4  
  
 Ø15 x 9 mm



Attach board 8 to board 28,  
 add cam lock(B) into board 8  
 and turn clockwise to tighten  
 as shown.




# 17




B x 4



Ø15 x 9 mm



Attach board 8 to board 4, add cam lock(B) into board 9 and turn clockwise to tighten as shown.



# 18



E x 16



Ø 4 x 35 mm




Fix board 6 and 7 to board 4 and 28 with screw(E) as shown.







# 19






Screw eccentric rod(A) into board 10 and 11 as shown.

Fix part(G) to board 11 and 10 with screw(D).



# 20





Connect board 12 and 31 to board 10 and 11 using wooden dowel(C), add cam lock(B) into board 12,31 and turn clockwise to tighten as shown.

# 21



B x 22



Ø15 x 9 mm



Attach the component to bottom,  
add cam lock(B) into and turn  
clockwise to tighten as shown.




# 22


H x 1



Stick light strip to the base.  
The USB connector is routed  
from board 5 and board 31.



Stick light strip to board 7.



# 24

B x 12




Ø15 x 9 mm

C x 12




Ø8 x 30 mm




E x 4




Ø4 x 35 mm




Cover board 1 to the top using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.  
Fix board 1 to board 9 with screw(E) as shown.






# 25


A x 10  
  
 Ø6 x 35 mm




Screw eccentric rod(A) into board 14 as shown.






# 26



A x 20  
  
 Ø6 x 35 mm





Screw eccentric rod(A) into board 15 as shown.






# 27







Screw eccentric rod(A) into board 16 as shown.



# 28



Fix runner(DL) and (DR) to board 20 and 30 with screw(D) as shown.





# 29


F x 40



Ø4 x 30 mm




Fix board 20, 26 and 30 to board 25 with screw(F) as shown.



# 30

Insert bottom board 27 along available grooves as shown.





# 31




B x 10



Ø 15 x 9 mm



Attach board 14 to board 20, 26 and 30, add cam lock(B) into and turn clockwise to tighten as shown.




# 32




B x 20



Ø 15 x 9 mm



Attach board 15 to board 20, 26 and 30, add cam lock(B) into and turn clockwise to tighten as shown.




# 33




B x 10



Ø 15 x 9 mm




Attach board 16 to board 20, 26 and 30, add cam lock(B) into and turn clockwise to tighten as shown.



# 34




A x 12





Ø 6 x 35 mm





Screw eccentric rod(A) into board 17 as shown.





# 35





Screw eccentric rod(A) into board 18 as shown.



# 36



Screw eccentric rod(A) into board 19 as shown.




# 37



B x 12



Ø15 x 9 mm




Attach board 17 to board 20, 22 and 30, add cam lock(B) into and turn clockwise to tighten as shown.



# 38

Insert bottom board 23 along available grooves as shown.




# 39


F x 12



Ø4 x 30 mm




Fix board 20, 22 and 30 to board 21 with screw(F) as shown.




# 40

Connect each board 24&34 at first.



# 41

Place the component into the drawer.




# 42




F x 30



Ø4 x 30 mm




Fix board 20, 26 and 30 to board 32 with screw(F) as shown.



# 43

Insert bottom board 27 along available grooves as shown.



# 44




B x 20



Ø 15 x 9 mm



Attach board 18 to board 20, 26 and 30, add cam lock(B) into and turn clockwise to tighten as shown.




# 45




B x 10





Ø15 x 9 mm



Attach board 19 to board 20, 26 and 30, add cam lock(B) into and turn clockwise to tighten as shown.



# 46






# 47



J x 4



K x 4




Fix layer pin(K) to board 4 and 28 as shown.



48

Place glass panel on the top.



# WARRANTY

## WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

## Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

## Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

## The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.