


Assembly Instructions




General Assembly Guidelines

Wood Care and Maintenance:

Like any natural wood, wood will maintain its attractive appearance for much longer when given proper care.

- I. To extend the life of your outdoor furniture, avoid placing wood furniture in direct sunlight for an extended period of time, as the sun's ultraviolet rays can cause the wood to dry out. Position patio furniture underneath an umbrella or canopy to minimize damage due to sun and rain. It is ideal to keep it covered when not in use, during in-climate weather, or while in storage.
- II. Cleaning - Clean spills from wood furniture with a soft cloth moistened with warm, soapy water. Dry the furniture with a second soft cloth or allow it to air-dry.
- III. Maintenance- Rub the wood furniture with a furniture wax or wood preservative product (we recommend Teak Wood Oil products). Apply the teak oil according to the instructions found on the product label. Apply additional applications, as needed, to restore the vitality of the wood.

Parts List




Hardware List

A		Ø6x45mm	Bolt	16 pcs
B		Ø8x80mm	Bolt	8 pcs
C			Washer	8 pcs
D			Spring washer	8 pcs
E		M4	Wrench	1 pc


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert top frame (2) into top frame (1).

Step 2




Use wrench (D) to secure part (3) to top frame (1,2) with bolt (C).

Step 3



Use wrench (D) to secure top frame (1,2) to leg (4) with bolt (B), washer (D), and spring washer (C).

Step 4



Final Assembly