

MODELS

SK-HX50

UBG-HX50-OR

UBG-HX50-YL

UBG-HX50-GR



www.upperbounce.com | support.upperbounce.com

US

📍 2 Mill St. Cornwall NY 12518

☎ 1-888-965-3331

✉ support@upperbounce.com

UK

📍 15-19 Garman Road, London N17 0UR

☎ 020-3150-0484

✉ support@upperbounce.co.uk


Safety Instructions

- To ensure the maximum safety of the trampoline, check it regularly for damaged and worn parts.
- If you pass on this trampoline to another person or if you allow another person to use it, make sure that the other person is familiar with the product and details outlined in this instructions booklet.
- Only one person at a time should use the trampoline.
- Before using the trampoline always make sure that the screws, bolts, and other joints are properly tightened and firmly secured.
- Before you start your work-out, remove all sharpedged objects around the trampoline.
- Only use the trampoline for your work-out if it works properly.
- Any broken, worn, or defective part must immediately be replaced. The trampoline must not be used until it has been properly repaired.
- Parents and other overseer should be aware of the situations which may arise when children use the trampoline. Parents should always supervise their children when using the trampoline. It must be used properly, this is not a toy.
- If you do allow children to use this trampoline, be sure to take into consideration and assess their mental and physical condition and development, and above all their temperament. Children should be instructed on the correct and proper usage of the trampoline.
- Make sure there is sufficient free space around the trampoline when you are using the trampoline.
- Please note that an improper and excessive work-out may be harmful to your health.
- Make sure that levers and other adjustment mechanisms are not projecting into the area of movement during use.
- When setting up the trampoline, make sure that the trampoline is standing on an even surface.
- Always wear appropriate clothing and shoes. The clothes must be designed in a way so that they will not get caught in any part of the trampoline during the work-out due to their form (for example, length). Be sure to wear shoes which firmly support your feet and have a non-slip sole.
- Be sure to consult a physician before you start any exercise program, they will properly advise you with respect to your individual ability.
- Maximum user Weight: 220 Lbs

Important notes

- Assemble the trampoline as per the assembly instructions and be sure to only use the structural parts provided with the trampoline. Prior to assembly, make sure the contents are correct by referring to the parts list on the assembly and operating instructions.
- Be sure to set up the trampoline in a dry and even place. Always protect it from humidity. If you wish to protect the trampoline particularly against pressure points, contamination, etc., it is recommended to put a suitable, non-slip mat under the trampoline.
- The general rule is that trampoline and exercise equipments are not toys. Therefore they must only be used under adult supervision.
- Stop using the trampoline immediately if you experience dizziness, nausea, chest pain, or any other physical symptoms. In case of doubt, consult your physician immediately.
- Disabled people, handicapped people, or children should use the trampoline under supervision and in the presence of another person who may provide support and advice.
- Be sure that your body parts and those of other persons are never close to any moving parts of the trampoline during use.
- When adjusting any parts, make sure they are adjusted properly and note the marked maximum adjusting position, for example of the saddle support, respectively.
- Do not use immediately after meals!


Parts list





PART #	ITEM	QTY
1	Frame tube	5
1-A	Frame tube with handrail holder	1
2	Leg	6
3	Mat	1
4	Bungee cord	42
5	Bottom handrail support	1
6	Upper handrail support	1
7	Handrail	1
8	Adjustment Knob	1
9	Small Bolt	4
10	Small Washer	8
11	Nut	4
12	Big Bolt	1
13	Wrench	2
14	Big Washer	1
15	Bungee cord assembly tool	1
16	Safety pad NOTE: This part is included if you purchased the models that includes the Pad	1

Steps to assemble the trampoline

Step 1 - Attach the frame tubes as shown in fig. below.




Step 2 - Remove the black caps that cover the leg connectors. Screw all legs onto the frame leg connectors. (It is the small threaded pieces that extends from the frame.)



Step 3 - Prepare the Mat-


Thread all the bungee cords individually (manual item #4) through the bungee holes at the end of the mat, (Manual Item #3). One bungee per Bungee hole.



Step 4 - Fasten the bungee cords to the frame tube.


First fasten the two bungee cords closest to every corner, as shown in the figure below. You will then fasten the remaining cords in an alternating manner on opposite sides of the trampoline to ensure even tension throughout the trampoline.

(Refer to the next page for illustrations on how to attach the bungee cords)




Steps to install the bungee cord


1




2




3




4




5




6





7




8




Step 5 - Assemble the bottom handrail support (Manual Item #5) to the frame (Manual Item #1-A) attaching it with the bolts, Washer and nuts, using the wrench, as shown in the following figure.



Step 6 - Assemble the upper handrail support (Manual item #6) to the bottom handrail support (Manual item #5), and lock it into its position with the adjustment knob (Manual item #8).




Step 7 - Assemble the handrail (Manual item #7) to the upper handrail support (Manual Item #6). Attach the handle by using the screws (Manual items 12 and 14), and tightening the screw with the wrench, as shown in the picture below.



If you purchased the trampoline that includes a safety pad then follow Step 8 (Otherwise skip this step)

Step 8 - Attach the pad to the mat of the trampoline with the Velcros, as shown in the figure below.



Step 9 - Trampoline Assembly is complete.



Hexagonal pads are also available in 3 other colors.
If you want to purchase other color pad you can select
from these model numbers :



SK-HX50PAD-OR (orange)
SK-HX50PAD-YL (yellow)
SK-HX50PAD-GR (green)



While we provide a large variety of trampolines, we also pride ourselves in the large selection of our trampoline replacement parts which are compatible with most trampolines regardless of their brand.

If you have difficulty finding the correct replacement part for your trampoline,
Please give us a call : **1-888-965-3331**
or email us at : **support@upperbounce.com**

Our Customer Service Department staff are trained in the details of all trampolines and will help you find the right part to get you bouncing again.

We never forget our goal... **Get the Upper Bounce!**